



# Exceed All Limits

Fast and powerful - the best specs in the history of Memory HiCorders



Usability

User-friendly design for accurate and smooth operation Intuitive operation via large 12.1-inch touch screen

Speed

Blazing fast, never-fail sampling High-speed isolation measurement at 200 MS/s

Storage

Radically improved data save time

Stress-free user experience

Long-term Recording

Superior processing capacity so you can save data during

measurement Save data in real time, 32 times faster than conventional models









## Overwhelming High-speed Technology A Revolutionary Approach to Measurement, Recording, and Analysis




## Flexible, User-friendly Design


Fast and convenient touch screen Operation as smooth as silk



The capacitive touch screen delivers intuitive operability. Select a setting item directly by tapping the screen, and use your fingers to enlarge the part you want to see.

This improved user interface makes setting measurement items for multiple channels easy.







▲ Tap the screen and use the knob to move the trace cursor as desired.

Video describing the MR6000's intuitive user experience https://www.youtube.com/watch?v=z7kFRPsub9U



# Highest Sampling Speed in the Entire Series

High-speed isolation measurement at 200 MS/s Up to 16 analog channels & 12-bit ADC resolution

The Hioki Memory HiCorder lineup now includes a powerful input unit that unlocks the full measuring potential of the MR6000.

The High Speed Analog Unit U8976 boasts the highest sampling rate in its entire series, an order of magnitude faster than conventional models, enabling the unit to perform isolated measurement at 200 MS/s\*.

\*200 MS/s measurements can be achieved even if a unit other than the U8976 is connected at the same time. However, the data update rate will not exceed the maximum sampling rate of the unit.



Max. 16 channels 12-bit ADC resolution

High Speed Analog Unit U8976

#### Blazing fast, never-fail sampling

The High Speed Analog Unit U8976 delivers a 30 MHz frequency band in addition to high-speed sampling at 200 MS/s. It has the performance needed to accurately capture switching waveforms during inverter evaluation testing, an application where high efficiency is critical. Adapted to the Memory HiCorder's direct input feature, it can accept inputs of up to 400 V DC.

#### Used in combination with the 10:1 Probe 9665

If you encounter issues with the capacitance components of connection cords, use the 10:1 Probe 9665 to reduce the effects on measured waveforms.




\*For more information about frequency deratings, either consult the user manual that comes with the 9665 or contact Hioki.

#### Isolated input with optical isolation devices

Connections between analog input channels, and between the input channel and the main unit, are fully isolated. This means that, unlike an oscilloscope, measurements can be made without concern with negative effects from potential differences.





No missed high-speed signals

Capture switching waveforms accurately

Available recording duration >>> 5-second continuous recording at 200 MS/s					
	h: hours m: minutes s: secon				
Sampling rate	1 ch	2 ch	3 to 4 ch	5 to 8 ch	9 to 16 ch
200 MS/s	5 s	2.5 s	1 s	0.5 s	0.25 s
100 MS/s	10 s	5 s	2 s	1 s	0.5 s
50 MS/s	20 s	10 s	4 s	2 s	1 s
20 MS/s	50 s	25 s	10 s	5 s	2.5 s
10 MS/s	1 m 40 s	to	20 s	to	5 s
1 MS/s	16 m 40 s	to	3 m 20 s	to	50 s
100 kS/s	2 h 46 m 40 s	to	33 m 20 s	to	8 m 20 s
to	to	to	to	to	to

\*Internal memory used \*U8976 installed in 8 slots

Video describing measurement at up to 200 MS/s ► https://www.youtube.com/watch?v=VsEu4FFyaFA



## Fastest Save Processing in the Entire Series


Radically improved data saving time Stress-free user experience



Transferring very large amounts of data measured over a long period of time used to be very time-consuming.

The MR6000 features a brand new interface and faster internal processing, reducing the time required to save measurement data to media.

For example, a save operation that took 1 minute on the previous model now completes in 2 seconds. This saves you the trouble of waiting for data to be saved and improves work efficiency.



## **Longest Continuous Recording in the Entire Series**

## Long-term recording and high-speed sampling in multiple channels Instant analysis of measurement results




The real-time save function controls the available measurement duration without relying on the capacity of the internal storage memory. For long-term recording, we recommend a high-capacity SSD or HD unit.

You can also use a more convenient USB memory stick or SD memory card. All phenomena can be recorded at a high sampling rate over a long period of time.

#### Saving data directly to your PC

Transfer measurement data directly to your PC by using the FTP sending function together with the real-time save function. This makes it easier to observe data after the measuring process.



#### Available real-time save duration for various media

Save destinations		Sampling rate	Number of channels	Available measurement duration	Maximum sampling rate for real-time save*1
SSD Unit U8332	(256 GB)	1 MS/s	32 ch	Approx. 1 h	20 MS/s
HD Unit U8333	(320 GB)	1 MS/s	16 ch	Approx. 2 h 40 m	10 MS/s
USB Drive Z4006	(16 GB)	1 MS/s	8 ch	Approx. 16 m	5 MS/s*2
SD Memory Card Z4003	(8 GB)	1 MS/s	8 ch	Approx. 8 m	5 MS/s
PC		1 MS/s	8 ch	Depends on PC capacity	5 MS/s

\*1: For 2 channels (no settings for 1 channel) \*2: When using the USB 3.0 connector

#### Maximum recording duration for real-time save with SSD UNIT U8332/Reference values

d: days h: hours m: minutes s: seconds

Sampling		*The values in () indicate the number of channels used.					
rate	2	4	8	16	32		
20 MS/s	53 m 20 s	_	_	_	_		
10 MS/s	1 h 46 m 40 s	53 m 20 s	_	_	_		
5 MS/s	3 h 33 m 20 s	1 h 46 m 40 s	53 m 20 s	_	-		
2 MS/s	8 h 53 m 20 s	4 h 26 m 40 s	2 h 13 m 20 s	1 h 6m 40 s	_		
1 MS/s	17 h 46 m 40 s	8 h 53 m 20 s	4 h 26 m 40 s	2 h 13 m 20 s	1 h 6m 40 s		
100 kS/s	7 d 9 h 46 m 40 s	3 d 16 h 53 m 20 s	1 d 20 h 26 m 40 s	22 h 13 m 20 s	11 h 6 m 40 s		
10 kS/s	74 d 1 h 46 m 40 s	37 d 0 h 53 m 20 s	18 d 12 h 26 m 40 s	9 d 6 h 13 m 20 s	4 d 15 h 6 m 40 s		
1 kS/s	to	to	185 d 4 h 26 m 40 s	92 d 14 h 13 m 20 s	46 d 7 h 6 m 40 s		



# An Extensive Line of Units for Detecting a Wide Range of Phenomena


Combine multiple units to record a range of phenomena. Use multiple logic units to measure relay ON/OFF signals or PLC (programmable logic controller) signals across up to 128 channels simultaneously. You can also measure temperature by attaching a thermocouple to a temperature unit





## Simultaneously measure up to 32 channels 4ch Analog Unit U8975

The U8975 accepts direct input of up to 200 V DC across 4 channels. With a sampling rate of 5 MHz (across a frequency band of 2 MHz), high speed, and 16-bit resolution, it can perform multi-channel, high-speed, and high-resolution measurement.



Simultaneous measurement of multiple locations across 32 channels at 5 MS/s






## Record frequency fluctuation and pulse count/integration data

#### Frequency Unit 8970

Use the Frequency Unit 8970 to record measured waveform frequency, RPM, input pulse integration, duty ratio, and pulse width variations. It can accommodate numerous use cases, including measurement of motor RPM, vehicle speed, and power supply frequency fluctuations. Thanks to a maximum input voltage of 400 V DC, it can also directly measure 3-phase circuit carrying up to 200 V.



Time




AC 700 V DC 1000 V

## Direct, high-voltage input without differential probes

#### High Voltage Unit U8974

The U8974 is ideal for measuring the primary and secondary sides of UPS power supplies and commercial power supply transformers. It can measure high-voltage power lines, including 380 V and 480 V circuits found many countries. With high-speed sampling at up to 1 MS/s and 16-bit resolution, it can also be used in load rejection testing and switch testing.





Analyze correlations between phenomena, including voltage levels before and after generator disconnection, RPM fluctuation rates, governor servo operating status, and voltage governor switching timing.




Maximum resolution 0.1 μV

## Specifically designed for DC voltage measurement with extremely high precision and resolution

#### Digital Voltmeter Unit MR8990

The MR8990 can measure minuscule fluctuations in sensor output of automobiles and voltage fluctuations in batteries, both at high precision and resolution. It can accommodate maximum input of 500 V DC. The unit is distinguished by its high input resistance. Additionally, the amount of space taken up by instruments can be reduced by replacing a bench-style DMM with the MR6000. Systems can be simplified by eliminating the need to control multiple instruments.



Battery

Battery package

#### NEW



4 ch 100 mV f.s.

# Simultaneously measure up to 32 channels at high resolution 4ch Analog Unit U8978

Thanks to four input channels and a high-sensitivity 100 mV f.s. range, the U8978 can measure multiple channels of output from a variety of sensors. The unit is ideal for use in measuring currents of various magnitudes in the development of automobile accessory controls. Utilized in combination with the multi-range Current Probe CT6711, it can measure currents from 1 mA to 50 A.


## Observe minuscule currents using high-sensitivity wideband current probes

#### Current probe lineup

Analyze minuscule current waveforms from low-power-consumption devices in 100 µA resolution. Record device current consumption waveforms in high resolution over extended periods of time.



Current consumption waveform for a temperature and humidity sensor




During measurement with the CT6711 (10 V/A range)



## High-speed sampling lets you accurately measure inrush current

#### High-Speed Analog Unit U8976

Combine the High-Speed Analog Unit U8976's 30 MHz frequency band with the Current Probe CT6711 to measure inrush currents and minuscule currents.



#### Power can be supplied from the MR6000.

Power can be supplied to current probes by using the Power Probe Unit Z5021.



Hioki offers a wide range of current probes to suit all frequency band and rated current needs.

#### NEW





## Single solution for 3-phase current measurement 3ch Current Unit U8977

The U8977 delivers a sampling rate of 5 MS/s, frequency characteristics of 2 MHz, 16-bit A/D resolution, and DC accuracy of 0.3% f.s. to facilitate wideband, high-precision current measurement using Hioki current sensors.

## Automatic configuration of sensor scaling values

When you connect a current sensor, the MR6000 will automatically detect the model and set the appropriate scaling value.



Connect sensors directly

## Power is supplied from the current unit

Since current sensor power is supplied directly from the current unit, there's no need to provide a sensor power supply.



## Compatible with high-precision sensors for measuring large currents

#### Current sensor lineup


Clamp-type high-accuracy sensors deliver excellent temperature characteristics, allowing highly accurate measurements to be made even in the confined space of a vehicle's engine compartment.



#### Sensitivity variations of high-accuracy clamp-type sensors caused by temperature CT6846-05 (1000 A), CT6845-05 (500 A) <u>rdg.</u>] CT6844-05 (500 A) CT6843-05 (200 A) Change in sensitivity (typical) [% 0.5 CT6841-05 (20 A) 0 Previous models -0.5 9279 (500 A) 9278 (200 A) 927 9277 (20 A) 9278 -60 -40 0 20 40 60 80 100 Ambient temperature [°C]

#### Zero-point stability


Wideband flux gate technology delivers high zero-point stability over extended periods of time.



Hioki offers a wide range of current sensors to suit all frequency band and rated current needs.


## CAN/CAN FD Measurement NEW

CAN buses carry not only control information, but also sensor information required by the ECU for control purposes. Analog values for sensor input signal quantities such as voltage, strain, temperature, flow rate, RPM, torque, vehicle speed, and vibration can be measured at the same time as these signals.



#### Load DBC files with the MR6000

Configure definitions simply by loading a DBC file. Consequently, there's no need to use a computer to configure definitions.




DBC file load screen

#### Transmit function

You can send data configured before measurement to the CAN bus at the start of measurement or when a trigger is activated.

\*This function is not supported for use with the SP7000 series Non-Contact CAN Sensor.



A shortcut key can be assigned to the transmit function.

#### **CAN** trigger function

You can use a CAN signal (frame) as a trigger source. The trigger will be activated when the set CAN signal type and ID is input.

Data frames
Remote frames
Set the ID used as the trigger source with a hexadecimal value.
Error frames

Error frames can be set as a trigger source.

#### Principal CAN signal measurement specifications

	•
Compatible instruments	Memory HiCorder MR6000/MR6000-01
Compatible interfaces	Vector VN1600 interface family
Number of interfaces that can be connected	Up to 1
CAN standards	CAN, CAN FD*
Number of CAN channels that can be measured	Up to 4*
Number of CAN signals that can be measured	All frame data on CAN bus
Number of CAN signals that can be displayed at once	Up to 16

<sup>\*</sup>Varies with the specifications of the Vector VN1600 product.

#### Hioki also offers CAN signal acquisition sensors

NEW Non-Contact CAN Sensor SP7001/SP7002

No modification of vehicle cables Acquire signals simply by pinching the cables with the probe.

No effect on the CAN bus or vehicle ECUs

Non-contact sensing technology

Accurate, reliable signal capture Ideal for use in development and evaluation applications



<sup>\*&</sup>quot;Vector" refers to the Vector Group, whose parent company is Vector Informatik GmbH.


## Real-time Waveform Processing Function


#### Real-time waveform processing

Exclusive MR6000-01 feature

#### Calculate measurement data during measurement

The MR6000-01 further features powerful technology designed for robust real-time waveform processing. This function performs the four arithmetic operations (addition, subtraction, multiplication, and division), differentiation calculations, or integration calculations during the measuring process, letting you use check the calculated results via waveforms while measuring or apply triggers during monitoring. Results can be further processed after measurement and saved.





Use calculation results as triggers

For example, you can calculate a differential waveform for input signals in real time and apply a trigger based on it. You can detect the timing of an input signal's local maximum and minimum values and output an external signal from the TRIG.OUT



Real-time waveform processing option


Simple setting method

#### Digital filter calculations


Exclusive MR6000-01 feature

#### Observe clear waveforms without noise

Remove harmonic noise or specific frequency noise from measurement data. Use it to eliminate the noise that cannot be resolved with the standard filter installed in the unit.









Digital filter enabled

#### Example FIR-LPF frequency characteristics




#### Example IIR-LPF (4th order) frequency characteristics



## Trigger Function

#### Triggers that detect targeted events


Set triggers on any channel to record data whenever an event occurs. Triggers can be set for all channels.




#### Setting multiple triggers for a single channel

Set up to 4 triggers for a single channel. If, for instance, you set the glitch, level, window-in, and window-out triggers for the same input waveform, that waveform is monitored according to the set trigger conditions.





Clear trigger system diagram



## Long-term Recording Functionality


In addition to the real-time save function, the MR6000 provides a range of functionality for extended recording.

#### Observe fluctuations over the long term with high-speed sampling Envelope function

The system uses the envelope measurement method to record maximum and minimum values at set intervals while performing oversampling at 100 MS/s. The internal memory has a capacity of 1 G-words, which ensures that the measuring process can continue for a long time without any data loss. Save data in real time while measuring.

Over-sampling speed	Recording interval	1 ch	 9 to 16 ch
	10 MS/s	50 s	 2 s
	1 MS/s	8 m 20 s	 20 s
	100 kS/s	1 h 23 m 20 s	 3 m 20 s
100 MS/s	10 kS/s	13 h 53 m 20 s	 33 m 20 s
100 IVIS/S	1 kS/s	5 d 18 h 53 m 20 s	 5 h 33 m 20 s
	to	to	 to
	20 S/s	289 d 8 h 26 m 40 s	 11 d 13 h 46 m 40 s
	to	to	 to

<sup>\*</sup>Limitations apply to measurable time when the U8975, U8977, U8978, or MR8990 is in use, and when performing real-time waveform processing.




## Measure anomalies during extended testing with high-speed sampling NEW Dual sampling function

In vibration testing, it's necessary to record comprehensive test data for several hours.

At the same time, it's necessary to capture areas of the waveform where anomalies occur with high-speed sampling for analysis once measurement is complete. The dual sampling function is useful in such situations.

#### (1) Record the entire trend waveform


Use the envelope function to record comprehensive test data for several hours.



#### (2) Check details with the instantaneous waveform

Anomalies occurring during the test will be captured with high-speed sampling based on triggers that have been set up in advance. By tapping on a trigger mark's number, you can display the instantaneous waveform for the anomaly that occurred at that waveform area.

#### Tap to enlarge the anomaly waveform



# 

#### Verify that no anomalies occurred during extended testing


#### No trigger marks

If no instantaneous waveform triggers activated, there were no anomalies. By viewing the trend waveform, you can not only verify that no anomalies occurred, but also check whether the device under test operated properly.

## Display Functions

#### Scroll function

You can use the scroll function to check the waveform as if viewing it on paper.




Scroll through the waveform with your finger

#### Zoom function


The zoom function allows you to display all measurement waveforms on a single screen, in the manner of an oscilloscope, and to view desired locations in greater detail.

Compressed display of entire recording length



Enlarged display of desired portion of waveform

#### Sheet function (display group)



## Waveform Search Function


#### Easily search for waveforms in huge volumes of measurement data

#### Memory HiCorder Concierge function

The Memory HiCorder Concierge function automatically calculates the characteristics of a reference waveform set by the customer and then searches all measured data while identifying waveforms that do not resemble the reference waveform as anomalous waveforms.

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually.

Additionally, this function is ideal for situations where it is difficult to set the right triggers before measuring because the nature of potential anomalies cannot be predicted.



#### Peak search

Search for the maximum value, minimum value, local maxima, or local minima in all of the measured data, and mark the search point in the waveform.

#### Trigger search

Set trigger conditions for all of the measured data again to search for points where the conditions are fulfilled, even if no triggers were set during the measuring process.

#### Jump

Jump to an event mark you made while measuring, to the cursor position on the display, or to the location measured at a specified time.

#### **Applications**


#### **Time Measurement**

By performing numerical calculations on measured waveforms, you can perform analyses using numerical parameters. Not only analog channels and logic channels, but also results of the real-time waveform calculation function can be used in this calculations.

#### Calculating switching times measured using logic channels (t1, t2, t3, T)

You can calculate time differences by applying numerical calculations to signals measured using logic channels.






Calculate the time difference T (s) at which waveforms A and B cross the specified level when either rising or falling.

Time difference T = Waveform B (time at which levels cross) - waveform A (time at which levels cross)

Reference channel (waveform A) calculation settings: Level Slope Filter

Calculation target channel (waveform B) calculation settings: Level Slope Filter



Measurement	waveforms	and des	ired time	differences


Trigger time	12:00.0
No. 1 time difference (t1)	1.50 s
No. 2 time difference (t2)	2.00 s
No. 3 time difference (t3)	1.00 s
No. 4 time difference (T)	4.50 s

Example above: numerical calculation results

## Calculating the time that elapses until a reading falls from the maximum value to a defined level (50 V) after a capacitor is charged during capacitor charge/discharge testing

You can calculate the desired value by calculating the time at which the maximum value occurs and the time at which the specified level occurs using numerical calculations and then performing your desired arithmetic operations.






- Calculate the maximum value time (A)
   Calculation settings: Time to maximum value
- Calculate the specified level time (B)
   Calculation settings: Level Slope Filte
- 3. Subtract (A) from (B) using arithmetic operations


No. 1

Calculation settings: Calculation Four

Four arithmetic operations No. 2



# Time to maximum value Calculate the time (s) from the trigger time until the maximum value. If the maximum value occurs at 2 or more points, the initial value will be treated as the maximum value.



#### Specified level time


The Memory HiCorder searches for the point at which the previously set level is crossed. It then calculates the time between the start of the calculation range to that level crossing point.

#### Four arithmetic operations Select the result of the numerical calculation and apply your desired arithmetic operations (addition, subtraction, multiplication, or division).

#### Calculating the motor inrush starting current time (t1)

You can derive the desired time by calculating the burst width using numerical calculations.





#### Calculate the time at which the burst signal is output

Calculate the duration of an oscillating signal, for example the inrush current when a motor starts operating, as the burst width.

Calculation settings:

Burst end filter
Window (upper limit, lower limit)

#### Available calculation functions

#### Numerical calculations Perform up to 32 of 33 available calculations simultaneously during measurement.

Average value	Rise time	Duty ratio	Amplitude
RMS value	Fall time	Pulse count	Overshoot
Peak-to-peak value	Standard deviation	Arithmetic operations	Undershoot
Maximum value	Area value	Time difference	+Width
Time-to-maximum value	X-Y area value	Phase difference	–Width


Minimum value	Specified level time	High level	Burst width
Time-to-minimum value	Specified time level	Low level	Integration values
Period	Pulse width	Median value	X-Y waveform angle
Frequency			

#### **Applications**

## Power Fluctuation Measurement

Use the MR6000's high-speed waveform processing and long memory to measure power fluctuations from the motor's start to stop. Since you can measure 3-phase voltage and current using just two slots, there's plenty of unit slots left over to simultaneously measure other phenomena such as vibration, temperature, RPM, and torque.

#### Record power fluctuations from motor start to stop



#### All-in-one measurement

The MR6000 displays a variety of power parameters along with voltage and current fluctuations for the duration of motor operation, from start to stop. You can review overall behavior by checking fluctuations along with parameters such as torque, RPM, vibration, and temperature.

#### High-speed data processing

Calculate and display power parameters immediately after measurement by using high-speed waveform processing. Processing speed has been improved compared to previous models.



#### Supply power from the instrument

Using the Power Cord 9248 and the Probe Power Unit Z5021, you can supply power to up to eight Differential Probe 9322s.

## Directly connect and automatically detect current sensors

Using the 3ch Current Unit U8977, you can directly connect and automatically detect Hioki high-precision current sensors.

#### Available calculation functions

#### Waveform processing function


Perform complex using previously loaded waveforms. Make up to 16 simultaneous calculations, including logarithmic conversions, various filters, and trigonometric functions. You can also compute the average value, maximum value, or minimum value of the loaded data and reuse the results in further waveform processing operations.



Supports complex calculations


#### NEW High-speed calculation of transient power

An operator has been added for averaging one period of the reference channel (full-cycle average). This operator can be used to check power fluctuations from motor start to motor stop.



Full-cycle average (AVEF)

#### Products used




\*The 4ch Analog Unit U8975 can be used when measuring 100 V AC or less.

# Applications Motor Torque and Vibration Measurement

Using a strain-gage-type converter or acceleration sensor, you can measure torque and vibration during motor operation. Discover unpredicted frequency components by using FFT calculations to perform a frequency analysis.

#### Record torque and vibration during motor operation



## Simultaneous measurement and instantaneous analysis

The torque sensor (strain-gage-type converter) is connected to the Strain Unit U8969 to measure torque.


An acceleration sensor affixed to the chassis on which the motor is mounted, is connected to the Charge Unit U8979 to measure vibrations being transferred to the chassis.

The MR6000's FFT calculation function can be used to perform a frequency analysis of torque and vibration signals.

#### Available calculation functions

#### FFT calculation function


The MR6000 can analyze 8 phenomena simultaneously per measurement. Multiple FFT analyses of signals input from different channels let you investigate the frequency components that appeared for each channel at a single point in time. Similarly, conduct a variety of analyses for a single signal simultaneously.



FFT calculation 4-split screen


#### FFT analysis directly from the measured data

Perform FFT analysis from measured data. Simply touch the screen to specify the starting point for analysis, while simultaneously viewing the calculation results.



Chronological order + FFT calculation screen

#### Products used




\*1 Strain-gage-type converter
\*2 Charge-output-type with built-in
pre-amp (IEPE type)
(For more information about
sensors, please contact the sensor
manufacturer.)

#### **Applications**

# Measurement of Dynamic Motor Characteristics

By using the X-Y display function with RPM on the X-axis, you can analyze fluctuations in torque, motor power, motor efficiency, and inverter output power for each RPM

#### Record fluctuations in various parameters from motor's start to stop



#### All-in-one measurement + pinpoint analysis

The signal from the torque sensor (Strain-gage-type converter) is measured with the Strain Unit U8969. Output from the motor's encoder (e.g. A-phase) is connected to the Frequency Unit 8970 to measure

The 3-phase inverter's voltage is measured using the 4ch Analog Unit U8978 and the Differential Probe 9322.

The 3-phase current is measured using the 3ch Current Unit U8977 and current sensors. Motor power, motor efficiency, and inverter output power are calculated after measurement using high-speed waveform processing, and the results are displayed using the instrument's X-Y display


#### Compositing over the specified X-Y interval

You can choose locations and generate an X-Y display of fluctuating waveforms from motor start to motor stop.

#### Available display functions

#### **NEW** X-Y display function

The MR6000 provides an extensive range of X-Y displays for captured waveforms, including an X-Y 1-screen display, X-Y 2-screen display, X-Y 4-screen display, and time series display + X-Y 2-screen display. The ability to use the X-Y display for waveform processing results as well as input signals from measurement units means that you can perform a broad range of analyses.



9322

3

4-screen X-Y display

#### XY waveform angle and area values

You can use the numerical calculation function on the X-Y display. Calculate XY waveform angle and area values using the numerical calculation function while viewing the X-Y display.

Calculate regression lines for the XY composite and then calculate the slope

$$SLOPE = \frac{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x}) \cdot (y_i - \overline{y})}{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x})^2} \\ \sum_{i=1}^{n} (x_i - \overline{x})^2 \\ \text{xi: ith data point for $X$-axis channel} \\ \theta = \arctan\left(SLOPE\right) \cdot \frac{180}{\pi} \left[ ^{\circ} \right] \\ \overline{x} \text{ Average value for $X$-axis channel} \\ \overline{y} \text{ Average value for $Y$-axis channel} \\ \overline{y} \text{$$

#### Calculate the area of the XY composite

X-Y area value (coordinate method) with multiple curves

manufacturers



 $S = n \times S0$ S: Area value n: Number of curves

Start point, end point

L9790

#### Products used



CT6843-05

3

- \*1 The 4ch Analog Unit U8975 can be used when measuring voltages of 100 V AC or less.
- \*2 Strain-gage-type converter (for more information about the sensor, please contact the sensor manufacturer.)

#### Software



Load data measured with the MR6000/ MR6000-01 onto a PC to display waveforms and perform calculations

Intuitive operation

Waveform processing


FFT calculations


Utilize functionality similar to that provided by the MR6000 on a PC, including numerical calculations, waveform processing, and FFT calculations. (Some restrictions apply.)

Supported models	MR6000, MR6000-01
Supported operating system	Windows 10 (64-bit) For other system requirements, please see the user manual.
	Free download from the Hioki website

#### Waveform display zoom

Zoom each axis in or out by spinning the mouse's scroll wheel while placing the cursor over either the left or bottom of the screen.





#### Functionality similar to the MR6000


unctionality and usability

You can display data, change settings, perform calculations, and save data in the MR6000 Viewer.




#### Ideal for creating reports

Copy a screenshot of the waveform screen to the clipboard.



#### Wave Processor 9335 (sold separately)

The 9335 provides waveform display, processing, and printing functionality.



#### Overview of 9335 specifications


	System equirements	Windows 10/8/7 (32-bit/64-bit)
F	unctionality	Display functionality: Waveform display, X-Y display, cursor function, etc.     File loading: Loadable data formats (.mem, .rec, .rms, .pow); The maximum loadable file is the maximum size of the Memory HiCorder being used. (The loadable file size is also dependent on the maximum size that can be saved by the PC being used.)     Data conversion: Conversion to CSV format, batch conversion of multiple files, etc.
F	Printing	Printing functionality: Save print image file (in .emf format) 1, 2, 4, 8, or 16 graphs; 2, 4, 8, or 16 rows, 1, 2, or 4 X-Y graphs; preview; hard copy.

#### Waveform Viewer Wv (standard accessory)

Download the latest version from Hioki's website.

Waveform Viewer Wv, which provides functionality for displaying and converting waveforms, is a standard accessory.

It allows you to review binary data for waveforms captured by a Memory HiCorder on a PC and convert it to CSV format so that it can be loaded by Excel.



#### - - 'Cart's as

Overview of Waveform Viewer (Wv) specifications

System requirements	Windows 10/8/7 (32-bit/64-bit)
Functionality	Simple display of waveform files     Conversion of binary-format data files to text format (e.g. CSV)     Scroll, display zoom in/out, jump to cursor/trigger point

#### Comparison with other Hioki software

Software	MR6000 Viewer	Wave Processor 9335	Waveform Viewer (Wv)
Waveform screen	Yes	Yes	Yes
Trace cursor	Yes	Yes	Yes
Saving	.csv, .txt, .set, .bmp, .png, .jpeg, binary, .flt	.csv, .txt	.csv, .txt
Settings	Yes*1	No	No
Printing	No	Screen image, detailed printing	No
Numerical calculations	Yes	Yes	No
Waveform processing	Yes	No	No
FFT calculations	Yes	No	No
X-Y display	Yes	Yes	No
Supported operating systems	Windows 10 (64-bit)	Windows 10, Windows 8, Windows 7 (32-bit, 64-bit)	
Price	Free	Varies with region	Free




Bringing Field Measuring Results to Your PC Simultaneous Observation of Data from Multiple Instruments


Data collection

Real-time performance Batch display and saving

GENNECT One lets you display and save data in real time on a PC during measurement. It also serves as a useful tool in measurement applications that include other instruments.



Simultaneous, real-time observation GENNECT One lets you display data from multiple instruments together and in real time in list or graph form.



#### LAN remote control function

Change instrument settings and control operation, for example to start or stop measurement



Example remote control screen

#### Smooth, simple configuration of settings in the software






Select the parameters to save and display.

Select which measurement parameters you wish to save or display.




Set the save/display interval. The intervals at which to save measurement data and refresh the display can be set separately\*



\*Monitoring interval ≤ Logging interval. The minimum interval depends on the network transmission speed.

#### Commercially available software

#### **FAMOS**




- · More than 400 calculation processing variables
- · Easy report creation functionality Download a free MR6000 import filter free of charge from Hioki's website.

#### FlexPro



- · High-speed search and processing of large volumes of data
- · Internal sharing of analysis templates

#### NI DIAdem



- · Functionality ranging from searching and loading of data to analyzing and creating of
- · Dialog-based interface

Control scripts and drivers On Hioki's website, search for MR6000 under "support" > "Software Downloads" to find downloadable drivers.


#### **MATLAB**

Available scripts allow you to directly load waveform data measured and saved using the MR6000's memory function, while control scripts let you start and stop measurement, acquire measurement data, and configure measurement settings.





#### LabVIEW

An available driver lets you control the MR6000 and acquire measurement data. The driver was created using LabVIEW 2009 sp1, and it has been confirmed to operate with LabVIEW 2017.



## **Multifunctional Interface**







Onen or close the top panel of the main unit Z4006 USB DRIVE installable

#### Only 6 keys in total New recorder design

Use the touch screen to configure all the basic settings.

#### Display

12.1-inch capacitive touch screen TFT color LCD display

#### USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### SAVE button

For displaying the manual save dialog box

#### Shortcut button 1

For registering frequently used settings

#### Shortcut button 2

For registering frequently used settings

#### Rotary knob X

For moving the tracing cursor and scrolling or zooming the waveform in and out

#### Rotary knob Y

For changing the position and zooming the waveform in and out

#### START button

To begin the measuring process

#### STOP button

For importing the set recording length and stopping the measuring process

#### Power button

For turning the power on or off

#### USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### USB 3.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### SD MEMORY CARD slot For inserting SD memory cards

Output terminal for probe compensation signals For outputting 10:1 or 100:1 PROBE compensation signals

#### KEY LOCK

For disabling the touch screen and buttons

For carrying the device

#### 1000 BASE-T connector

For connecting to a network via LAN cable

#### **DVI terminal**

For outputting the screen display

#### External sampling terminal

For inputting various external sampling signals

#### External control terminal

For inputting various external signals to control the device

## Dedicated power supply terminal for current sensors

For supplying power to current sensors (option)

#### Various units

Install input units appropriate for the measurement target


#### Air inlet

For reducing the internal temperature

#### Media box

For USB 3.0 connectors (USB memory sticks only)

#### Operability and visibility suited for a variety of work environments



Our search for a touch screen with the best operability and visibility angle led us to develop retractable feet that maximize those two important attributes. Tilting the MR6000 with the feet reduces

# Convenient long handle Robust design

#### Easy handling

The rubber handle boasts excellent grip and makes it easy to carry the device with either one or both hands. The grips on either side of the device can also be used to lift it with both hands.



#### Space-saving size

We have achieved a design that is compact while still delivering blazing fast processing speeds by using thermal liquid analysis to optimally position the air inlets, heating components, and cooling fans.

#### Sleek design

The beveled corners of the Memory HiCorder's body gives the device a compact and sleek look. This simple and refined appearance is sure to be a strong addition to the creative environment of any R&D workspace.

#### Ergonomical operating angle

the strain on your wrists when you use the device on a desk, and keeps your line of sight at a natural level.





#### **Product Specifications**

in Post-adjustment accuracy guaranteed for 1 year)  mal: Regular waveform recording leope: Periodically recording maximum and minimum values leope setting not available with external sampling I sampling: Records waveforms at a sampling speed different from the leope sampling speed during envelope measurement.  log with up to 32 channels (with 4ch ANALOG UNIT U8975/U8978)  c with up to 128 channels (LOGIC UNIT 8973)  mrnon GND for the logic probe input connector and main unit  MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76)  mal sampling (10 MS/s)  words  lors, pollution degree 2, altitude up to 2000 m (6562.20 ft)  to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  dupply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations lated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations lated supply voltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings  , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  kg (229.3 oz) (main unit only)  gg (236.3 oz) (with T5021, U8332, or U8333 installed)  gg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (ober 23°C ±5°C (73°F±9°F), 80% RH or less  1005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
relope setting not available with external sampling I sampling: Records waveforms at a sampling speed different from the elope sampling speed during envelope measurement. log with up to 32 channels (with 4ch ANALOG UNIT U8975/U8978) c with up to 128 channels (LCGIC UNIT 8973) mmon GND for the logic probe input connector and main unit  MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76) mal sampling (10 MS/s) words lors, pollution degree 2, altitude up to 2000 m (6562.20 ft) to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  ty: EN61010, EMC EN61326 and supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) and you with z5021, U8332, or U8333 installed) are cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (operature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 10005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
elope sampling speed during envelope measurement.  log with up to 32 channels (with 4ch ANALOG UNIT U8975/U8978) c with up to 132 channels (LOGIC UNIT 8973) mmon GND for the logic probe input connector and main unit  MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76) mroal sampling (10 MS/s) words  lors, pollution degree 2, altitude up to 2000 m (6562.20 ft)  to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  ty: EN61010, EMC EN61326 ad supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage) do power supply frequency: 50 Hz / 60 Hz cipated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor  rmm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) rg (229.3 oz) (main unit only) rg (236.3 oz) (with Z5021, U8332, or U8333 installed) rg (236.3 oz) (with T5021, U8332, or U8333 installed) rg (236.3 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) re cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), ication disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 1000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%		
log with up to 32 channels (with 4ch ANALOG UNIT U8975/U8978) c with up to 128 channels (LOGIC UNIT 8973) mmon GND for the logic probe input connector and main unit MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76) mral sampling (10 MS/s) words  lors, pollution degree 2, altitude up to 2000 m (6562.20 ft) to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  Lty: EN61010, EMC EN61326  and supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage) of power supply frequency: 50 Hz / 60 Hz inpated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings  , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) arg (229.3 oz) (main unit only) arg (236.3 oz) (with 25021, U8332, or U8333 installed)  gr (373.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (operature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 10005%		
c with up to 128 channels (LOGIC UNIT 8973) mmon GND for the logic probe input connector and main unit  MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76) rral sampling (10 MS/s) words  ors, pollution degree 2, altitude up to 2000 m (6562.20 ft) to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  ty: EN61010, EMC EN61326  ad supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) vg (229.3 cz) (main unit only) vg (236.3 cz) (with Z5021, U8332, or U8333 installed) vg (313.9 cz) (with HIGH SPEED ANALOG UNIT U8976 installed) ver cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (operating precautions to the substitution of the color of the col		
MS/s (all channels at the same time) (with HIGH SPEED ANALOG UNIT 76) mral sampling (10 MS/s) words wo		
76) roal sampling (10 MS/s) words  ors, pollution degree 2, altitude up to 2000 m (6562.20 ft) to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  tty: EN61010, EMC EN61326  dd supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage) dd power supply frequency: 50 Hz / 60 Hz cipated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) vg (229.3 cz) (main unit only) vg (236.3 cz) (with 25021, U8332, or U8333 installed) er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 0000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%		
words  ors, pollution degree 2, altitude up to 2000 m (6562.20 ft)  to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  tty: EN61010, EMC EN61326  sid supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage)  dg opwer supply frequency: 50 Hz / 60 Hz  cipated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings  , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  vg (229.3 cz) (main unit only)  vg (236.3 cz) (with 25021, U8332, or U8333 installed)  vg (313.9 cz) (with 4HIGH SPEED ANALOG UNIT U8976 installed)  vg croct, Ouick Start Manual (booklet, CD-R), operating precautions (booklet), ication disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (obor)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  1005%		
to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  ty: EN61010, EMC EN61326  Id supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage)  Id power supply frequency: 50 Hz / 60 Hz ippated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings  , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  rg (229.3 cz) (main unit only)  rg (236.3 cz) (with 25021, U8332, or U8333 installed)  rg (336.3 cz) (with 25021, U8332, or U8333 installed)  rg cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (booklet, CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 10005%		
to 40°C (32°F to 104°F), 80% RH or less (non-condensing)  C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  ty: EN61010, EMC EN61326  dd supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage) dd power supply frequency: 50 Hz / 60 Hz cipated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) vg (229.3 cz) (main unit only) vg (236.3 cz) (with 25021, U3332, or U8333 installed) gr (313.9 cz) (with HIGH SPEED ANALOG UNIT U8976 installed) er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), caction disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 0000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%		
C to 50°C (14°F to 122°F), 80% RH or less (non-condensing)  thy: EN61010, EMC EN61326  and supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations atted supply voltage)  and supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations atted supply voltage)  and power supply frequency: 50 Hz / 60 Hz  cipated transient overvoltage: 2500 V  VA		
ty: EN61010, EMC EN61326  Indicated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage)  Indicated supply requency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted supply frequency: 50 Hz / 60 Hz injusted supply frequency: 50 Hz / 60 Hz /		
ty: EN61010, EMC EN61326  Indicated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage)  Indicated supply requency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted transient overvoltage: 2500 V  VA  Indicated supply frequency: 50 Hz / 60 Hz injusted supply frequency: 50 Hz / 60 Hz injusted supply frequency: 50 Hz / 60 Hz /		
d supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations ated supply voltage) d power supply frequency: 50 Hz / 60 Hz cipated transient overvoltage: 2500 V VA -calendar, leap-year correcting 24-hour clock rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor rmm (1390 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) vg (229.3 oz) (main unit only) vg (236.3 oz) (with 25021, U8332, or U8333 installed) vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) vg cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), ication disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 0000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 0005%		
ated supply voltage) dip ower supply frequency: 50 Hz / 60 Hz cipated transient overvoltage: 2500 V  VA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor  rmm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  rg (229.3 oz) (main unit only)  rg (236.3 oz) (with 25021, U8332, or U8333 installed)  rg (313.9 oz) (with E5021, U8332, or U8333 installed)  rg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  re cord, Ouick Start Manual (booklet, CD-R), operating precautions (booklet), ication disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual  5000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  1005%		
cipated transient overvoltage: 2500 V VA		
vA  -calendar, leap-year correcting 24-hour clock  rox. 10 years (at 23°C (73°F)) for clock and settings , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  kg (229.3 oz) (main unit only)  g (236.3 oz) (with TSD21, U8332, or U8333 installed)  gg (313.9 oz) (with HIGH SPEED AINALOG UNIT U8976 installed)  er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 0000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
rox. 10 years (at 23°C (73°F)) for clock and settings  , USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  vg (229.3 oz) (main unit only)  vg (236.3 oz) (with Z5021, U8332, or U8333 installed)  vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  vg cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet),  cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual  source of the control		
, USB, SD, SATA, monitor  mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions)  vg (229.3 oz) (main unit only)  vg (236.3 oz) (with Z5021, U8332, or U8333 installed)  vg (313.9 oz) (with HIGH SPEED, ANALOG UNIT U8976 installed)  vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed)  vg cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet),  cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual  source of the control of the c		
mm (13.90 in) W x 235 mm (9.25 in) H x 154.8 mm (6.09 in) D (excluding protrusions) vg (229.3 oz) (main unit only) vg (236.3 oz) (with Z5021, U8332, or U8333 installed) vg (313.9 oz) (with Z5021, U8332, or U8333 installed) vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) vg cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual (booklet, CD-R), blank panel (blank slot only) vg cation disk (CD-R), instruction Manual (booklet, CD-R), blank panel (blank slot only) vg cation disk (CD-R), vg cation (cd. R), vg cation (vg cation) vg cation		
vg (229.3 oz) (main unit only) vg (236.3 oz) (mith Z5021, U8332, or U8333 installed) vg (313.9 oz) (with Z5021, U8332, or U8333 installed) vg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) vg (common terms of the common terms of the com		
rg (236.3 oz) (with Z5021, U8332, or U8333 installed) gr (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) gr crord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), ccation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 0000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 0005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
kg (313.9 oz) (with HIGH SPEED ANALOG UNIT U8976 installed) er cord, Quick Start Manual (booklet, CD-R), operating precautions (booklet), cation disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 6000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
ication disk (CD-R), Instruction Manual (detailed edition) (CD-R), Instruction Manual 6000-01 exclusive functions edition) (CD-R), blank panel (blank slot only)  perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
perature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 1005%  inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
inch XGA TFT color LCD (1024 x 768 dots) with capacitive touch screen		
802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T		
802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T		
DHCP, DNS, FTP, HTTP, e-mail sending function  RJ-45		
m (328.11 ft)		
20 compliant v 2 UCB 20 compliant v 4		
USB 3.0 compliant x 3, USB 2.0 compliant x 4		
Connector: Series A receptacle Connected devices: Keyboard, mouse, USB memory stick		
06 USB MEMORY STICK (16 GB)		
pliant with SD standards x 1 (compatible with SD, SDHC, SDXC memory cards)		
MEMORY STICK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)		
al ATA Revision 3.0 compliant x 1		
32 SSD UNIT (256 GB), U8333 HD UNIT (320 GB)		
tal output* and analog output for external display 4 × 768 (XGA)		
al-link not supported		
inal		
3		
'DC		
V to 10 V for high level, 0 V to 0.8 V for low level		
s or more during high periods, 50 ns or more during low periods		
MHz		
rnal sampling clock input ng, falling, rising & falling (user-selectable)		
als		
n-button type		
n-button type mum input voltage 10 V DC		
···		
num input voltage 10 V DC		
mum input voltage 10 V DC tr voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level		
mum input voltage 10 V DC  It voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level sonse pulse width 50 ms or more during high periods, 50 ms or more during low periods		
mum input voltage 10 V DC  It voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level sonse pulse width 50 ms or more during high periods, 50 ms or more during low periods e interval 200 ms or greater		
mum input voltage 10 V DC  It voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level sonse pulse width 50 ms or more during high periods, 50 ms or more during low periods interval 200 ms or greater 200 ms or greater		
num input voltage 10 V DC  It voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level  sonse pulse width 50 ms or more during high periods, 50 ms or more during low periods  e interval 200 ms or greater  sher of terminals 2  strions START, STOP, START/STOP, SAVE, ABORT, event		
num input voltage  10 V DC  1t voltage  2.5 V to 10 V for high level, 0 V to 0.8 V for low level  2.5 v to 10 V for high level, 0 V to 0.8 V for low level  50 ms or more during high periods, 50 ms or more during low periods  e interval  200 ms or greater  aber of terminals  2 START, STOP, START/STOP, SAVE, ABORT, event  but type  Open drain output (active low, with 5 V voltage output)		
num input voltage  10 V DC  11 voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level  10 vonse pulse width 50 ms or more during high periods, 50 ms or more during low periods  10 v periods 200 ms or greater  10 v periods 200 ms or more during high periods, 50 ms or more during low periods  20 to ms or greater  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or greater  20 v periods 20 ms or more during high periods, 50 ms or more during low periods  20 v periods 20 ms or greater  20 v periods 20 m		

	Maximum input voltage	10 V DC
	External trigger filter	ON / OFF
	Response pulse width	External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods
External trigger	Functions	Rising, falling, rising & falling (user-selectable) Rising: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V), Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to low (0 V to 0.8 V) or when a terminal short circuit occurs.  "When the trigger timing is set to [START&STOP], the edge to be used can be chosen between rising, falling, and both rising & falling for each of [START] and [STOP].)
	Output type	Open drain output (active low, with 5 V voltage output)
		4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level
Trigger output	Output voltage  Maximum input voltage	50 V DC, 50 mA, 200 mW
Trigger output	Output pulse width	Level or pulse selection possible Level: Sampling period x data number after trigger
Output terminal for	probe correction	Pulse: 2 ms ±1 ms signals
Output signals	0 V to 5 V ±10%, 1 k	:Hz ±1% square waves
Functions	10:1 PROBE 9665, 1	100:1 PROBE 9666 correction
Dedicated power su *Option to be specified u	upply terminal for pon order placement (	current sensor with PROBE POWER UNIT Z5021 installed)
Number of terminals	8	
Output voltage	± 12 V ± 0.5 V DC	
Trigger *Not available	when the real-time say	ve function is used
Trigger type	Digital comparison t	уре
Trigger conditions		n for trigger sources and interval trigger
Trigger source	When START or ST "Up to 4 analog tri "Up to 4 logic trigg "Up to 2 analog trigg When START&STO Analog: Up to 16 cl Logic: Up to 16 pl Real-time waveform "Up to 2 trigger ty	me waveform processing OP is selected: Up to 32 channels iggers can be set for each analog channel. gers can be set for each logic probe. gers can be set for each logic probe. gers can be set for each real-time waveform processing channel. P is selected: Up to 16 channels / group hannels / group (Up to 2 channels per unit can be selected.) robes / group (Up to 2 probes per unit can be selected.) n processing: Up to 16 calculations / group pes from each group can be set for each analog channel. gers from each group can be set for each logic probe.
		n is activated if all trigger sources are turned off.
	Level trigger	Triggering occurs when the set level rises (falls).
	Voltage drop trigger	Triggering occurs when peak voltage drops below the set level. (For a 50 Hz / 60 Hz commercial power supply only) *1, *2, *3
	Window trigger	Sets the upper and lower limit for trigger level. Triggering occurs when leaving (OUT) or entering (IN) the area. *1
Analog triggers	Period trigger	Sets the period reference value and cycle range. Triggering occurs when the rising (falling) reference value period is measured and determined to be outside or within the cycle range. *1, *2, *3
	Glitch trigger	Sets the reference value and pulse width (glitch width). Triggering occurs if the value is below the set pulse width from rising or falling of the reference value. *1, *Not available with MR8990, *3
	Specifying events	Specifying events (1 to 4000) Counts the number of times conditions were fulfilled for each trigger source. Triggering occurs when the set number of times is reached. *Not available when the trigger conditions are set to AND
		*1: Disabled when sampling rate is set to 200 MS/s. *2: Not available with MR8990 or 8970 *3: Not available with envelope setting
Logic trigger	Pattern trigger using	1, 0, or x
Forcible trigger	Included (Forcible tr	riggering can be prioritized over all trigger sources.)
CAN trigger	The instrument is trig or remote frame.	ggered when receiving a specific data frame, error frame,
Interval trigger	The trigger condition	t specified measuring intervals (hours, minutes, or seconds) as are fulfilled when the measuring process starts. per conditions are met at the set measuring intervals.
Trigger filter	Normal	OFF, 10, 20, 50, 100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples
Time In the state of	Envelope	OFF, 1 ms, 10 ms
Trigger level setting resolution	1 LSB	lug opt in 10/ stone oveilable) dienle 's a the second'
Pre-trigger	0% to 100% (any va time for pre-trigger	lue set in 1% steps available), displaying the recording
Post-trigger	0% to 40%, displaying	ng the recording time for post-trigger
Trigger priority	ON / OFF	
Trigger mark	Displays trigger marks for the positions where triggers are set.	
Trigger timing	START, STOP, STAF	
Waveform monitoring display	Displays the wavefo be turned off.)	rm monitor in the trigger standby state. (The display can
Waveform screen	·	
	Time-domain waveform representation	1, 2, 4, 8, 16 screens (Up to 64 channels can be displayed on each sheet.) (Every channel can be set to be displayed on multiple sheets.)
Display format	XY composite waveform display	sneets.)  1, 2, 4 screens, combination of time-series waveforms and XY (2 screens) (Unsettable when envelope is enabled) (Up to eight XY composite waveforms can be set) (Multiple sheets can display the same composite waveforms)
	FFT display	1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)
		(, =,

Sheet function	Up to 16 sheets	*The display format can be selected for each sheet.	Repeated		ecified number of times *Repeated measurements cannot be
Zoom display	ON / OFF (Waveforms are displayed in chronological order in the top part of the waveform screen, whereas the zoomed waveforms are displayed in the bottom part.)		measurements  Waveform monitoring function	set and the number of times cannot be specified for real-time saving.  Displayed on the channel setting screen	
Full screen display	Displays waveforms Waveform color Interpolation	over the entire waveform screen.  Fixed colors (32 colors)  Linear	Scaling	Conversion ratio and *Model: Select a mo	offset / 2-point input / Model / Output rate / dB / Rating odel to configure the scaling settings automatically. and automatic scaling are available when a current unit is used.
	Variable display Always ON		Comments	Title comments, channe	el comments
Waveform display	Vernier	Adjustable input waveform (Adjustment range: 50% to 250% of the input)		Calculation formulas	nannel comments are added on the setting screen and waveform screen.
	Grid Logic display width	OFF / ON Wide / Standard / Narrow		Calculation targets	Measurement channels in 8966, 8967, 8968, U8969, 8970, 8971, 8972, U8974, U8975, U8976, U8977, U8978, U8979 "The 8973 and MR8990 measurement channels are not applicable.
Enlarge / Reduce	Waveform inversion Displays waveforms upside down. *Not available with 8967, 8970, and 8973  Allows you to adjust the zoom ratio as necessary by pinching in or out.		Digital filter	Calculation update rate	10 M / 1 M / 100 k / 10 k / 1 k / 100 / 10 / 1 [S/s] *Up to 8 calculations can be set for 10 MS/s.
Waveform scrolling		swiping the screen and scroll back while measuring.	*MR6000-01 only (Option to be specified		*Up to 16 calculations can be set for 1 MS/s.  Calculation 10MS/s 1 MS/s 100 MS/s 10 M
Roll display mode	The drawing start po	latest data by following the measuring process. sition (left or right edge) can be selected. displayed when the overlay function is turned on.	upon order)	Calculation delay	update rate 10 MS/s 1 MS/s 100 KS/s 10 KS/s of less
Waveform monitoring function		tor can also be displayed in the trigger standby state.)			delay 6.3 us 5 us 20 us rate period
Overlay		or manual option can be selected.		Filter types	FIR (LPF / HPF / BPF / BSF), IIR (LPF / HPF / BPF / BSF), moving average, delay device
	The foil cannot be c	displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.	Saving		
	Tracing cursor	*Displays potential, time from trigger, time difference between cursors, and potential difference.		SD MEMORY CARD USB MEMORY STICK	Z4001 (2 GB), Z4003 (8 GB)
Cursor	Horizontal cursor	Up to 8 cursors can be displayed. *Displays potential and potential difference.		SSD	U8332 SSD UNIT (256 GB)
	Gauge	Up to 8 gauges can be displayed.	Save destination	HDD	U8333 HD UNIT (320 GB)
	Specifying segments	Segment cursor 1 / Segment cursor 2 *Specifies the calculation range, saving range, and search range.		Sending to FTP	PC with a LAN connection
	Jump	Tap the screen to jump to the specified location.		Sending e-mails	Send files via e-mail to specified address
Event mark		g the measuring process (up to 1000 marks) or external input terminal for input.	Backup	can be set for use in	on is FTP or email transmission, an alternate destination in the event communications fail.
Setting screen			File format	FAT, FAT32, NTFS, (	or USB drive (user-selectable)
		200 M, 100 M, 50 M, 20 M, 10 M, 5 M, 2 M, 1 M 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k	Filename	Alphanumeric and J	
		500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s] *The speed for real-time waveform processing can be set	Processing identical		aber at the beginning before saving
	Normal	from 100 MS/s.	filenames		iber at the beginning before saving
		External sampling: Depending on the input signal of the external sampling terminal Up to 10 MHz  10 M, 5 M, 2 M, 1 M  500 k, 200 k, 100 k, 50 k, 10 k, 5 k, 2 k, 1 k	Auto saving	measuring process *Settings files are no *This function is not	ot supported. available when real-time saving is selected.
	Envelope	500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s] 30, 12, 6, 2, 1 [S/min]			ry segmentation, measurement of the next block can start nitations on sampling rate and recording length apply.)
		*Calculation speed for maximum and minimum values *Oversampling rate: 100 MS/s		ON / OFF	m data (binary) obtained during the measuring process
		[Instantaneous waveform] 100 M, 50 M, 20 M, 10 M, 5 M, 2 M, 1 M	Real-time saving		destination. *The auto saving function is not available.
		500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k 500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s]		File division	Files are divided for approx. every 512 MB of data. Divides a file at specified intervals.
		*A sampling rate faster than that chosen for trend waveforms can be chosen.  *When the real-time waveform calculation is used, a sampling rate of 50 MS/s or slower can be chosen.	Deleting and saving	free space left on th	n the oldest creation dates and saves data when there is no be specified media at the save destination. aving and real-time saving.
Sampling rate	Dual sampling	[Trend waveform]  10 M, 5 M, 2 M, 1 M		Settings data	SET
		500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k 500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s]		Waveform data	Binary format (.MEM, .REC, .FLT), text format (.TXT, .CSV)  Divided saving (.IDX), memory segmentation (.SEQ), dual
		30, 12, 6, 2, 1 [S/min] *The sampling rate represents a rate at which maximum and	Types of saved data	Index	sampling batch save (.R_M)
		minimum values are calculated.  *The instrument performs oversampling at the sampling rate set for instantaneous waveforms.	Types of saved data	Displayed images  Numerical calculation results	.BMP, .PNG, .JPG
		Maximum available sampling rate	-	Startup	STARTUP.SET
		[Save destination: SSD] 20 MS/s (2 channels), 10 MS/s (4 channels), 5 MS/s (8 channels), 2 MS/s (16 channels),		CAN frame data	Binary format (.CLG), text format (.TXT, .CSV)
	For real-time	1 MS/s (32 channels), 500 kS/s (64 channels) [Save destination: HDD] 10 MS/s (2 channels), 5 MS/s	Saving channels	Select a channel fro when saving wavefo	m all the channels available or from the displayed channels orm data.
	*The values in ( )	(4 channels), 2 MS/s (8 channels), 1 MS/s (16 channels), 500 kS/s (32 channels), 200 kS/s (64 channels) [Save destination: SD memory card, USB memory stick,	Culled data saving	Waveform data (text (from 2 to 1000) bef	t format) is culled according to the specified culling value
	indicate the number of	sending via FTP] 5 MS/s (2 channels), 2 MS/s (4 channels), 1 MS/s (8 channels), 500 kS/s (16 channels),		Types of saved data  Division method	
	channels used.		File division *Real-time saving and	Binary format	OFF / Every 16 MB of data / Every 32 MB of data / Every 64 MB of data
			memory segmentation excluded	Text format	OFF / Every 60,000 points of data / Every 1,000,000 points of data
		3.0 connector.		Numerical calculation results	OFF / By the calculation number
		[Built-in presets] 20 M (32 channels), 50 M (16 channels), 100 M (8 channels), 200 M (4 channels), 500 M (2 channels), 1 G (1 channel)	Specifying files		les *Enabled when numerical calculation results are saved. te a new file or add data to an existing file when starting to measure.
	Normal	[Point] [Arbitrary recording length] 33554400 (32 channels), 67108800 (16 channels), 134217700 (8 channels), 268435400 (4 channels), 536870900 (2 channels), 1073741800 (1 channel) [Point] "Setting is possible in units of 100 points.		Instant saving	Press the SAVE button to save data to a save destination, under a filename, and with saving settings that have been pre-set.
			SAVE button operation	Saving range	Select the full range or a specific segment. *Enabled only when data is saved with the SAVE key.
		[Built-in presets] 10 M (32 channels), 20 M (16 channels), 50 M	Loading data		Enabled only when data is saved with the SAVE key.
	Facultura	(8 channels), 100 M (4 channels), 200 M (2 channels), 500 M (1 channel) [Point]	_ouug uu.u	SD MEMORY CARD	24001 (2 GB), Z4003 (8 GB)
	Envelope	[Arbitrary recording length] 16777200 (32 channels), 33554400 (16 channels), 67108800 (8 channels), 134217700 (4 channels),		USB MEMORY STICK	Z4006 (16 GB)
		268435400 (2 channels), 536870900 (1 channel) [Point] *Setting is possible in units of 100 points.	Loading source	SSD	U8332 SSD UNIT (256 GB)
		[Instantaneous waveform] Less than half of the maximum recording length provided		HDD	U8333 HD UNIT (320 GB)
Dual sampling  Maximum recording		for the normal method [Trend waveform]		Settings data (.SET) Waveform data	Binary format (.MEM, .REC)
		1/2 of maximum recording length listed under "Envelope" or less	Types of loaded data	batch (.R.	
length	For real-time saving	Determined according to the amount of free space in the save destination, file system, and number of measurement channels		Startup (STARTUP.SI	
		theses above show the number of channels to be used.	Numerical calculati	ions *Not available w	vith envelope setting
	Definition of the number 1. For modules with two	er of channels to be used	Maximum number of calculations	32 items x Measurer	ment channels
	Consider that use of or	ne input channel occupies one channel.  ly, consider that use of one input channel occupies two channels.	Calculation range	Full range / Specifie	d segments
	2. For modules with thre	ly, consider that use of one input channel occupies two channels. ee or four input channels (Models U8975, U8977, U8978) f either CH1 or CH2 or simultaneous use of CH1 and CH2			Peak to peak value, maximum value, minimum value, high-level, low-level, average value, effective (RMS) value,
	occupies one channe	l.			standard deviation, rise time (*), fall time (*), frequency (*), period (*), duty ratio (*), pulse count, area value, X-Y
	occupies one channe				area value, time difference (*), phase difference (*), time to
	occupies two channel		Calculation items	Normal	maximum value, time to minimum value, specified level time, specified time level, pulse width (*), four arithmetic operations, median value, amplitude, integration value,
		calculation ression occupies one channel. of Model U8975, U8977, U8978, and MR8990 or the real-time			operations, median value, amplitude, integration value, burst width (*), X-Y waveform angle, overshoot, undershoot, +width (*), -width
	waveform calculation	is used, each maximum recording length reduces to half or less			*Statistical function available for: Beginning, average, maximum, minimum, waveform processing results
	for a sampling rate of	TO MIOJO OF SIOWEL.		L	

	Targeted				nels, real-time waveform
Numerical judgment	waveforms  Judgment settings	ON / OFF	nannels	, waveform	processing results
	Stop conditions	PASS, FAIL,	PASS&F	AIL	
Waveform processin	g *Not available with	envelope setting	not avail	lable simultar	eously with real-time saving
Maximum number of calculations	16 formulas				
Calculation range	Full range / Specifie	d segments			
Maximum recording length					
Standard operator	+, -, x, ÷  Absolute value, exp	onentiation, co	mmon le	ogarithm, m	oving average.
Calculation items	derivative, integral, s cube root, parallel m ATAN2, FIR (LPF, H	secondary der nove, PLC shift PF, BPF, BSF) period, half-wa quency, CAN, evel at specific	ivative, s i, SIN, C IIR (LPI ive frequ average ed time (	secondary i OS, TAN, A F, HPF, BPF Jency, full-v value (*), r (*)	ntegral, square root, SIN, ACOS, ATAN, F, BSF), half-wave vave average, full-wave maximum value (*),
Averaging function		10,000) able when the av g equation uses	eraging three cal	function is tu lculation spo	
Real-time waveforn	n processing *C	Option to be spe	cified up	oon order (C	order code: MR6000-01)
Maximum number of calculations	16 formulas	nala ia 0000 0	007 000	20 110000 (	2070 0074 0070 0070
Calculation targets	U8974, MR8990 (*), *The MR8990 DVM UNIT	U8975, U8976 performs calcula	6, U8977 tions only	7, U8978, U for the top 16	3970, 8971, 8972, 8973, 8979 bits of the 24-bit AD resolution.
Calculation update rate	10 M, 1 M, 100 k, 10 *Up to 8 calculations	s can be set fo	r 10 MS	s/s. *Some ty	ypes of calculations
	cannot be set with c Calculation update rate	10 MS/s	1 MS/s	100 kS/s	10 kS/s or less
	Calculation delay	6.2 or 6.3 us	5 us	20 us	Calculation update rate period
Calculation delay	Add the delay times li selected for calculation		en real-tii	me waveforr	n processing channels are
	Calculation update rate	10 MS/s	1 MS/s	100 kS/s	10 kS/s or less
	Added calculation delay	1.6 us	2 us		Calculation update rate period
Calculation type					ations with coefficients, quartic rentiation, integrals, integration,
	FIR (LPF / HPF / BPF / B	SF), IIR (LPF / HP	F / BPF / E	BSF), moving a	average, delay device
		ope setting, not	availabl	e simultane	ously with real-time saving
Maximum number of calculations Frequency range	8 500 mHz to 100 MH	z (samnling ra	te v0 5)	evternal sa	ampling
Number of sampling points	1 k, 2 k, 5 k, 10 k, 20			, external se	aripiirig
Frequency resolution	1/500, 1/1000, 1/250			/25,000, 1/5	50,000
Anti-aliasing filter	AAF (8968, U8979),				
	waveform processin				
Calculation targets	Analog waveform, wav				aveform processing results
Analyzed data  FFT analysis modes	Newly loaded Data newly measured by pressing START key  Memory Data measured most recently or data loaded from media  Linear spectrum*, RMS spectrum*, power spectrum*, 1CH phase spectrum, cross power spectrum, transfer function, coherence function, 2CH phase spectrum				
TTT dildiysis modes	*Total harmonic disto	ortion (THD) is o	lisplayed	with a curs	or set to on.
	Rectangular Hanning	ı, Hamming, Bla	ckman, I	Blackman-Ha	arris, Flat-top, Exponential
	+	ala			
Display scale	Linear scale, log sca	-	e		
Display scale Peak value display	Linear scale, log sca OFF, local maxima,	maximum valu		peak hold (	arbitrary setting from
Display scale Peak value display Averaging function	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times)	maximum valu xponential ave	eraging,	peak hold (	
Display scale Peak value display Averaging function Calculation execution button	Linear scale, log sca OFF, local maxima, Simple averaging, e	maximum valu xponential ave	eraging,	peak hold (	
Display scale Peak value display Averaging function Calculation execution button Memory division	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis	maximum valu xponential ave	eraging,	peak hold (	
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis	maximum valu xponential ave	eraging,		arbitrary setting from
Windows Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis 1024 blocks Search from the dat Superimposes wave The waveforms pres	maximum valu xponential ave splayed in scre a that is saved eforms of a spe sently displaye	eraging, een in divid	led memory	arbitrary setting from block.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis 1024 blocks Search from the dat Superimposes wave The waveforms pres	maximum valuxponential average as that is saved a special forms of a special transition of the saved at the saved at the saved at waveform days as the saved at waveform days as the saved at the saved	eraging, een in divid ecific blod d on the	led memory ock. s screen car s loaded in	arbitrary setting from block.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block	Linear scale, log sca OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis 1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured	maximum valuxponential ave splayed in screet at that is saved eforms of a speantly displayed dwaveform de bof data in all bluevel, windo Logic trigger selected as t	in divide in divide don the tat that is ocks las w-in, wirr search he targe	ed memory pck. screen car s loaded in tt measured indow-out is available	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is al.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis 1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured Saves entire range of	maximum valuxponential ave splayed in scree at that is saved eforms of a speantly displayed d waveform de of data in all bluevel, windo Logic trigger selected as t "Logic trigger"	in divide edific blood on the tat that is ocks lassw-in, wirr search he targer search	ed memory ock. screen car s loaded in tt measured indow-out is available ted channe is not availa	arbitrary setting from  block.  be compared with the reference block.  when a logic channel is all, able with envelope setting.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis 1024 blocks Search from the dat. Superimposes wave The waveforms pres previously measured Saves entire range of	maximum valuxponential ave splayed in screet at that is saved efforms of a specially displayed d	in divided and in divided and the tat that is search he targer search use, minintandard ner to co to the di	ded memory bock. s screen car s loaded in tt measured adow-out is available ted channe is not availa- num value, k deviation mirectly prac-	arbitrary setting from  block.  block when a logic channel is arbitrary setting from
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms pres previously measured Saves entire range of	maximum valuxponential ave splayed in screet at that is saved at that is saved aforms of a speantly displayed dwaveform de do	raging, in dividicific blod in dividific	ed memory bock. s screen car s loaded in the measured is available sted channe is not availa unum value, k deviation ompare eac irectly prec- ope setting ne (absolute	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is all. with envelope setting. ocal maxima, local minima h value to the reference eding waveform.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured Saves entire range of  Trigger  Peak  CONCIERGE	maximum valuxponential ave splayed in screet at that is saved at that is saved aforms of a speantly displayed dwaveform de do	in dividing in din	led memory lock. I screen car I loaded in It measured Indow-out Is available I set available I num value, k deviation I mpare eac irrectly precope setting I e (absolute I er of points)	arbitrary setting from  block.  block when a logic channel is sl.  suble with envelope setting.  cal maxima, local minima  h value to the reference eding waveform.  time, relative time, or time, trigger point, search mark
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured Saves entire range of  Trigger Peak  CONCIERGE  Jump	maximum valuxponential ave splayed in screet at that is saved aforms of a speantly displayed dis	in dividid to the first search when we have a search be target and to the did the target and the target and the target and the did the search when the target and the did the search to the did the search the target and the target to the did the search the target target the target target the target ta	ded memory bock.  Is screen car is loaded in it measured and ow-out is available sted channe is not available num value, ked viation is one available except per setting the record per setting in the interest precedure of points), in the interest per specified specified specified in the interest per specified specified specified in the interest per specified in the interest	arbitrary setting from  block.  be compared with the reference block.  when a logic channel is all able with envelope setting. and maxima, local minima in value to the reference eding waveform.  time, relative time, or time, trigger point, search mark nall memory
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measurer Saves entire range of  Trigger  Peak  CONCIERGE  Jump Full range Specifying	maximum valuxponential average at that is saved efforms of a special year of data in all blue and the special year. Level, windo Logic trigger selected as the select whether the specified by the All of the data.	in dividid dividid in dividid in dividid in dividid in dividid in dividid dividid in dividid dividid in dividid divi	ded memory bock.  Is screen car is loaded in it measured and ow-out is available sted channe is not available num value, ked viation is one available except per setting the record per setting in the interest precedure of points), in the interest per specified specified specified in the interest per specified specified specified in the interest per specified in the interest	arbitrary setting from  block.  be compared with the reference block.  when a logic channel is all able with envelope setting. and maxima, local minima in value to the reference eding waveform.  time, relative time, or time, trigger point, search mark nall memory
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search Search method Search range Number of searches	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times)  Execution button dis  1024 blocks  Search from the dat. Superimposes wave The waveforms pres previously measuret  Saves entire range of  Trigger  Peak  CONCIERGE  Jump  Full range  Specifying segments	maximum valuxponential ave splayed in scree at that is saved eforms of a speartly displayed of data in all blue and the specification of the data in all blue and the specification of the data in all specification of the data in all specified by the specified by the specified for 000 data point	in dividid dividid in dividid in dividid in dividid in dividid in dividid dividid in dividid dividid in dividid divi	ded memory bock. It is screen car is loaded in it measured available sted channe is not available sted channe is not available mum value, it, deviation in mpare each in each precedure ope setting the (absolute er of points) in the internal perspecified.	arbitrary setting from  block.  n be compared with the reference block.  when a logic channel is all.  solution block is a local maxima, local minima is a local maxima, relative time, or time, trigger point, search mark nall memory.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times)  Execution button dis  1024 blocks  Search from the dat. Superimposes wave The waveforms pres previously measures  Saves entire range of  Trigger  Peak  CONCIERGE  Jump  Full range Specifying segments  Specifiable (Up to 1 Built-in unit, real-time Cursor can be move	maximum valuxponential ave splayed in screet at that is saved at that is saved aforms of a speantly displayed dwaveform de do f data in all blue by the speantly displayed the speantly	in dividid  in div	led memory lock, screen cars loaded in at measured and ow-out is available teed channed is not available teed channed is not available mum value, k deviation ampare each green in the interest of points) in the interest of points in the interest of screen in the interest of scre	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is is. is. is. is. is. is. is. is. is.
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times)  Execution button dis  1024 blocks  Search from the dat. Superimposes wave The waveforms pres previously measuret  Saves entire range of  Trigger  Peak  CONCIERGE  Jump  Full range Specifying segments  Specifiable (Up to 1  Built-in unit, real-time Cursor can be mode.	maximum valuxponential ave splayed in scree at that is saved eforms of a speantly displayed divaveform de of data in all blue before the selected as the selected whether waveform or "Disabled with selectified by the selectified for select	in divididiciping in dividiciping in divididiciping in divididicip	ded memory bock.  In screen car is loaded in it measured hadow-out is available sted channer is not available sted channer each form of the composition of the compos	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is sill ble with envelope setting bocal maxima, local minima h value to the reference eding waveform.  time, relative time, or time trigger point, search mark nal memory.  If or segment 1 or the one in calculation
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position Continuous search	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured Saves entire range of  Trigger Peak  CONCIERGE  Jump Full range Specifying segments Specifipiable (Up to 1 Built-in unit, real-tim Cursor can be move After a search is exe	maximum valuxponential ave splayed in screet at that is saved eforms of a speantly displayed waveform de of data in all blue by the selected as the selected as the selected as the selected waveform or "Disabled with selected waveform or "Disabled with selected waveform or "Disabled with selected either specified for "Oo0 data point et waveform or et	in dividid  in div	led memory look.  screen cars loaded in at measured and ow-out is available teed channed is not available teed channed is not available memorable. It deviation ampare each green in the interest of points, in the interest per specified it 2.  g, waveform can be set re search h rm data folk.	arbitrary setting from  block.  the compared with the reference block.  when a logic channel is also block with envelope setting, and make a logic channel is also be with envelope setting, and make a logic maxima, local minima the value to the reference eding waveform.  time, relative time, or time trigger point, search mark hall memory.  If or segment 1 or the one on calculation at, search positions.  Its in the search range
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position Continuous search Display method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times)  Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms pres previously measures Saves entire range of  Trigger  Peak  CONCIERGE  Jump  Full range Specifying segments Specifiable (Up to 1 Built-in unit, real-time Cursor can be move After a search is exe beyond the specifie point is continued for Specify a search loc	maximum valuxponential ave splayed in screet at that is saved eforms of a speantly displayed waveform de of data in all blue by the selected as the selected as the selected as the selected as the selected waveform or "Disabled with selected waveform or "Disabled with selected waveform or "Disabled with selected either specified for selected the selected in the data waveform or et al." All of the data selected either specified for selected either specified for selected waveform or et al. The selected either specified for selected either specified for selected either se	in dividid  in div	led memory look.  screen cars loaded in at measured and ow-out is available teed channed is not available teed channed is not available memorable. It deviation ampare each green in the interest of points, in the interest per specified it 2.  g, waveform can be set re search h rm data folk.	arbitrary setting from  block.  the compared with the reference block.  when a logic channel is also block with envelope setting, and make a logic channel is also be with envelope setting, and make a logic maxima, local minima the value to the reference eding waveform.  time, relative time, or time trigger point, search mark hall memory.  If or segment 1 or the one on calculation at, search positions.  Its in the search range
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Batch save Waveform search  Search method  Search range Number of searches	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespreviously measured Saves entire range of  Trigger Peak  CONCIERGE  Jump Full range Specifying segments Specifiable (Up to 1 Built-in unit, real-tim Cursor can be move After a search is expeyend the specifie point is continued for Specify a search loc  Compliant	maximum valuxponential ave splayed in screet at that is saved eforms of a speantly displayed waveform de of data in all blue by the selected as the selected as the selected as the selected as the selected waveform or "Disabled with selected waveform or "Disabled with selected waveform or "Disabled with selected either specified for selected the selected in the data waveform or et al." All of the data selected either specified for selected either specified for selected waveform or et al. The selected either specified for selected either specified for selected either se	in dividid dividid in dividid in dividid in dividid in dividid in dividid dividid in dividid dividid in dividid divi	led memory bock. It is screen car is loaded in it measured in it is available ted channe its not available in it is not in it in it is not in it in it is not available in it in it is not in it in it in it is not in it in it in it is not in it in it in it is not available in it in it in it is not available in it in i	arbitrary setting from  block.  the compared with the reference block.  when a logic channel is also block with envelope setting, and make a logic channel is also be with envelope setting, and make a logic maxima, local minima the value to the reference eding waveform.  time, relative time, or time trigger point, search mark hall memory.  If or segment 1 or the one on calculation at, search positions.  Its in the search range
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position Continuous search Display method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms pres previously measure. Saves entire range of  Trigger  Peak  CONCIERGE  Jump  Full range Specifying segments Specifiable (Up to 1 Built-in unit, real-time Cursor can be move After a search is exe beyond the specifie point is continued for Specify a search loc  Compliant standards Supported	maximum valuxponential ave splayed in screet at that is saved eforms of a speantly displayed of data in all blue and the selected as the selec	in divididicific block of the transport of tra	led memory sock. a screen car s loaded in st measured and ow-out is available steed channed is not available steed in the steed of points). In the interfer of points, in the interfer search in the steed is not available steed in the steed is not available steed in the steed is not available steed in the ste	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is all with envelope setting, ocal maxima, local minima h value to the reference eding waveform.  time, relative time, or time trigger point, search mark nall memory.  If or segment 1 or the one in calculation at, search positions. Its in the search range owing the last search
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position Continuous search Display method	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespresiously measured Saves entire range of  Trigger  Peak  CONCIERGE  Jump Full range Specifying segments Speciffiable (Up to 1: Built-in unit, real-time Cursor can be move After a search is exe- beyond the specifie- point is continued to Specify a search loc  Compliant standards Supported products	maximum valuxponential ave splayed in screet at that is saved aforms of a speantly displayed of waveform day and the speantly displayed of data in all blue of data in	in divididicific block of the transport of tra	led memory sock. a screen car s loaded in st measured and ow-out is available steed channed is not available steed in the steed of points). In the interfer of points, in the interfer search in the steed is not available steed in the steed is not available steed in the steed is not available steed in the ste	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is el. bible with envelope setting, ocal maxima, local minima h value to the reference eding waveform.  time, relative time, or time trigger point, search mark nall memory I for segment 1 or the one at, search positions. its in the search range wing the last search
Display scale Peak value display Averaging function Calculation execution button Memory division Max. divisions Block search Reference block Batch save Waveform search  Search method  Search range Number of searches Target channels Search position Continuous search  Display method  CAN measurement	Linear scale, log sci OFF, local maxima, Simple averaging, e 2 to 10,000 times) Execution button dis  1024 blocks Search from the dat. Superimposes wave The waveforms prespresiously measured Saves entire range of  Trigger  Peak  CONCIERGE  Jump Full range Specifying segments Speciffiable (Up to 1: Built-in unit, real-time Cursor can be move After a search is exe- beyond the specifie- point is continued to Specify a search loc  Compliant standards Supported products	maximum valuxponential ave splayed in screet splayed in screen spl	in dividididicific blocks lass with a market search	led memory lock. In screen cars loaded in at measured and ow-out is available steed channed is not available steed in the steed in the steed is not available steed in the steed in the steed is not available steed in the steed is not available steed in the steed in	arbitrary setting from  block.  h be compared with the reference block.  when a logic channel is sl. sl. slible with envelope setting. coal maxima, local minima h value to the reference eding waveform.  time, relative time, or time trigger point, search mark hall memory I for segment 1 or the one on calculation at, search positions. Its in the search range wing the last search

	Number of input CAN ports	Up to 4 (C1 to C4) When 4 transceivers are affixed to VN1630A or VN1640
	Baud rate	33.3 k, 50 k, 83.3 k, 100 k, 125 k, 250 k, 500 k, 1 M [baud]
	Data rate	33.3 k, 50 k, 83.3 k, 100 k, 125 k, 250 k, 500 k, 1 M, 2 M, 4 M [baud] *Setting available only when CAN FD is selected.
Interface		11-bit (standard), 29-bit (extended)
	Acceptance filter	Block setting is available for all frames.
	ACK	Normal / ACK OFF
	Storage memory	CAN frame data inputted in synchronism with the start of measurement can be stored in the build-in memory (up to 10 MB). Data is cleared every time measurement starts.
	Monitor function	Yes
		Signal number: From 1
		Signal name: up to 32 characters  ID: 0 to 1FFFFFFF
		Start bit: 0 to 511
	Definition settings	Bit length: 1 to 64
Signal settings		Byte order: Big / Little
Signal settings		Data type: Signed, Unsigned, Float, Double
		Conversion into physical quantity:Conversion using conversion ratio and offset
	Number of signals that can be registered	Up to 300
	Input method	Direct entry using the instrument's screen, or import of CANdB file (.DBC)
	Configuration method	Select the operation CAN and designate signal numbers
Waveform display	Number of waveforms that	Up to 16
	can be displayed Timing	Key S1, Key S2, Start, Trigger, Reply, Pass, Fail, Error
	Transmit ID	0 to 1FFFFFFF
	Transmit port	C1 to C4, ALL
	Types	Standard CAN, extended CAN, standard CAN FD, extended CAN FD, standard CAN remote, extended CAN remote
Transmit function	DLC	0 to 8, 12, 16, 20, 24, 32, 48, 64
	Delay	0 to 10000 ms
	Periodic transmit	Repeated transmission (select key S1, key S2, or start)
	Interval	Transmit interval can be set for regular transmission: 1 to 10000 ms
	Response ID	0 to 1FFFFFFF (if timing is set to response)
Other  Auto setup	Available previousl	e power is turned on, the unit loads the settings data y saved (STARTUP.SET) to start up. D/SSD. SD memory card. and USB memory are searched. in
	Available previousl *The HDI that orde	y saved (STARTUP, SET) to start up.  O/SSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or
	Available previousl *The HDI that orde  X In the hor display p  In the ver	y saved (STARTUP, SET) to start up.  2/SSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  tical direction, the measurement range, compression rate,
Auto setup	Available previousl *The HDI that orde  X In the hor display p  Y In the ver or display	y saved (STARTUP, SET) to start up.  2/SSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  tical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.
Auto setup  Rotary knobs	Available previous]  Available previous that orde  In the hordisplay p  In the ver or display  S1, S2 A function  Available (The optimaveform are autor	y saved (STARTUP, SET) to start up.  O/SSD, SD memory card, and USB memory are searched, in  r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rtical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)
Auto setup  Rotary knobs  Shortcut button  Auto range	Available previous]  Available previous are the HDI that orde  In the hor display p  In the ver or display  S1, S2 A function  Available (The optimaveform are autor "Not available for e	y saved (STARTUP, SET) to start up.  O/SSD, SD memory card, and USB memory are searched, in  r, for the save location.  rizontal direction, the sampling rate, compression rate, or  osition can be changed and the cursor can be moved.  rtical direction, the measurement range, compression rate,  y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input  matically set.)  nvelope, real-time saving, or external sampling.
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock	Available previous]  The HDI that orde  X In the hor display p  Y In the ver or display  S1, S2 A function  Available (The optis waveform are autor who available for e  Three levels of setti and hard buttons.	y saved (STARTUP, SET) to start up. JOSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input matically set.) nuclope, real-time saving, or external sampling. ngs are available: OFF, touch screen only, or touch screen
Auto setup  Rotary knobs  Shortcut button  Auto range	Available previous]  The HDI that orde  X In the hor odisplay p  Y In the ver or display  S1, S2 A function  Available (The optis waveform are autor Not available for e  Three levels of setti and hard buttons.  OFF, alarm only, al.	y saved (STARTUP, SET) to start up. OSSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. In can be allocated. In the sampling rate and measurement range for the input matically set.) In real-time saving, or external sampling. In gs are available: OFF, touch screen only, or touch screen
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound	Available previous]  The HDI that orde  X In the hor display p  Y In the ver or display  S1, S2 A function  Available (The optis waveform are autor who available for e  Three levels of setti and hard buttons.	y saved (STARTUP, SET) to start up. OSSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. In can be allocated. In the sampling rate and measurement range for the input matically set.) In real-time saving, or external sampling. In gs are available: OFF, touch screen only, or touch screen
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock	Available previous]  The HDI that orde  X In the hor display profit of the HDI that orde  X In the hor display profit of the HDI that orde  X In the hor display profit of the HDI that order that order has been display to the HDI that order th	y saved (STARTUP, SET) to start up.  JOSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rtical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  novelope, real-time saving, or external sampling.  In ga are available: OFF, touch screen only, or touch screen arm and operation  a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails	Available previous Brite HDI that orde  X In the hor display p Y In the ver or display S1, S2 A function  Available (The optive waveform are autor waveform are autor waveform are belief or et al. (The optive waveform are autor waveform are waveform are waveform only, al. Sending e-mails via Sending timing  Sent data	y saved (STARTUP, SET) to start up.  JOSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In each can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  matically set.)
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound	Available previous 1 The HDI that orde  X In the hor display p Y In the ver or display S1, S2 A function Available (The optis waveform are autor "Not available for e Three levels of setti and hard buttons.  OFF, alarm only, al. Sending e-mails via Sending timing Sent data  Waveform data initi	y saved (STARTUP, SET) to start up.  JOSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rtical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  novelope, real-time saving, or external sampling.  In ga are available: OFF, touch screen only, or touch screen arm and operation  a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization	Available previous 1 The HDI that orde  X In the hor display p Y In the ver or display S1, S2 A function Available (The optis waveform are autor "Not available for e Three levels of setti and hard buttons.  OFF, alarm only, al. Sending e-mails via Sending timing Sent data  Waveform data initi	y saved (STARTUP, SET) to start up.  JCSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rizontal direction, the measurement range, compression rate, y position can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In exampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range, compression rate, or complete input matically  In can be moved.
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check	Available previous]  The HDI that orde  X In the hor display p Y In the ver or display p S1, S2 A function  Available (The optive waveform are autor waveform are autor waveform are dutor waveform are dutor waveform are waveform are autor waveform and hard buttons.  OFF, alarm only, al. Sending e-mails via Sending timing  Sent data  Waveform data initit Memory, LCD, butt English, Japanese,	y saved (STARTUP, SET) to start up.  JCSD, SD memory card, and USB memory are searched, in r, for the save location.  rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved.  rizontal direction, the measurement range, compression rate, or osition can be changed and the cursor can be moved.  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In example and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range for the input matically set.)  In can be allocated.  mal sampling rate and measurement range, compression rate, or can be moved.
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language	Available previous Previous Management of the Available Previous Management of the Available (The option of the Available (The option of the Available for each of the Availab	y saved (STARTUP, SET) to start up. JASD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, ry position can be changed and the cursor can be moved. In can be allocated. In can be allocated. In a sampling rate and measurement range for the input matically set.) Invelope, real-time saving, or external sampling. Ings are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data. Italization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese s of errors and warnings when they occur. reen keyboard.
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard	Available previous In the hor display previous In the hor display previous In the very or display In the very	y saved (STARTUP, SET) to start up. JOSSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. In can be allocated. In can be moved. In can be moved
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display	Available previous In the hor display previous In the hor display previous In the very or display In the very	y saved (STARTUP_SET) to start up. JOSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. In can be allocated. In all sampling rate and measurement range for the input matically set.) In real-time saving, or external sampling. In gas are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button Attach data specified in the main text or files specified by a type of saved data. Italization, setting initialization, complete initialization ons, LAN, media, touch screen Chinese s of errors and warnings when they occur. reen keyboard. It point and break characters in data saved to waveform
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications	Available Previous Previous Previous State	y saved (STARTUP_SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rtical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input matically set.) numble, real-time saving, or external sampling. ngs are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button Attach data specified in the main text or files specified by a type of saved data. falization, setting initialization, complete initialization ons, LAN, media, touch screen Chinese s of errors and warnings when they occur. reen keyboard. al point and break characters in data saved to waveform errical calculation result files Period, comma Comma, space, tab, semicolon
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display	Available Previous Previous Previous State	y saved (STARTUP, SET) to start up. JOSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input matically set.) rical direction, the measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical sampling rate and measurement range, compression rate, or observed and input sampling rate, or observed rate, or
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display	Available Previous Previous Management of the Available Previous Management of the Available (The option waveform are autor Not available (The option waveform are autor Not available for e Three levels of setti and hard buttons.  OFF, alarm only, al. Sending e-mails via Sending e-mails via Sending timing  Sent data  Waveform data initi Memory, LCD, butt English, Japanese, Displays the details Displays the details Displays the on-scr Settings for decima (text) files and num Decimal point Break  Hours, sexagesima  ON / OFF	y saved (STARTUP, SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input matically set.) rical direction, the measurement range for the input matically set.) rical sampling rate and measurement range for the input matically set.) rical personal sampling. rical sampling rate and measurement range for the input matically set.) ricel personal sampling. ricel save available: OFF, touch screen only, or touch screen arm and operation a SMTP Automatic saving, saving with the SAVE button Attach data specified in the main text or files specified by a type of saved data. falization, setting initialization, complete initialization ons, LAN, media, touch screen Chinese so of errors and warnings when they occur. reen keyboard. al point and break characters in data saved to waveform rerical calculation result files Period, comma Comma, space, tab, semicolon
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color	Available Previous Deviated National Previous Standard Previous Previous Standard Previous Pr	y saved (STARTUP, SET) to start up. JOSSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ossition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input natically set.) nuclope, real-time saving, or external sampling. ngs are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data. falization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese s of errors and warnings when they occur. reen keyboard. all point and break characters in data saved to waveform errical calculation result files  Period, comma  Comma, space, tab, semicolon all time, date, data values
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission	Available Previous Detributed or Wallable Previous Standard Previous Previous Standard Previous Previo	y saved (STARTUP, SET) to start up. JOSSD, SD memory card, and USB memory are searched, in r., for the save location. r., for the save location. r., for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input natically set.) rical direction, the measurement range for the input natically set.) rical sampling rate and measurement range for the input natically set.) rical provides the saving, or external sampling. rical sampling are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data. falization, setting initialization, complete initialization ons, LAN, media, touch screen  Chinese of errors and warnings when they occur. reen keyboard. all point and break characters in data saved to waveform refrical calculation result files  Period, comma  Comma, space, tab, semicolon all time, date, data values
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings	Available Previous Description of the August Previous Procession of the August Previous Previ	y saved (STARTUP, SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input natically set.) rical direction, the measurement range for the input natically set.) rical person of the input natically set. rical person of the input natically set. rical direction is saving, or external sampling. rical sampling rate and measurement range for the input natically set.) rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically. rical first firs
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission	Available Previous Detributed or Wallable Previous Standard Previous Previous Standard Previous Previo	y saved (STARTUP, SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input natically set.) rical direction, the measurement range for the input natically set.) rical person of the input natically set. rical person of the input natically set. rical direction is saving, or external sampling. rical sampling rate and measurement range for the input natically set.) rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically. rical first firs
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings	Available previous In The HDI that orde  X	y saved (STARTUP, SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. n can be allocated. mal sampling rate and measurement range for the input natically set.) rical direction, the measurement range for the input natically set.) rical person of the input natically set. rical person of the input natically set. rical direction is saving, or external sampling. rical sampling rate and measurement range for the input natically set.) rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically set. rical sampling rate and measurement range for the input natically. rical first firs
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings  Time settings  System protection	Available Previous Development of the August Protects and	y saved (STARTUP, SET) to start up. JOSDS, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or ostition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. rical direction, the measurement range for the input matically set.) rical provides a saving, or external sampling. rical sampling rate and measurement range for the input matically set.) rical provides a saving, or external sampling. rical sampling are available: OFF, touch screen only, or touch screen arm and operation a SMTP  Automatic saving, saving with the SAVE button  Attach data specified in the main text or files specified by a type of saved data. rialization, setting initialization, complete initialization rical salization, setting initialization, complete initialization rons, LAN, media, touch screen  Chinese  s of errors and warnings when they occur. recen keyboard. rical point and break characters in data saved to waveform recical calculation result files  Period, comma  Comma, space, tab, semicolon  at time, date, data values  and "Permitted: If settings are changed during the measuring process, the remitted: Settings cannot be changed during the measuring process, the remitted: Settings cannot be changed during the measuring process, or set the display to turn off automatically.  The reconstruction and mounting an reconstruction and mounting an
Auto setup  Rotary knobs  Shortcut button  Auto range  Key lock  Beep sound  Sending e-mails  Initialization  Self-check  Language  Error and warning display  Touch keyboard  Region specifications  Time value display  Zero position display  Waveform screen background color  Restart permission  Display settings  Time settings  System protection function  Number of current	Available Previous Previous Previous State of the August Protects the System and Interest The	y saved (STARTUP, SET) to start up. JOSSD, SD memory card, and USB memory are searched, in r, for the save location. r, for the save location. r, for the save location. rizontal direction, the sampling rate, compression rate, or osition can be changed and the cursor can be moved. rical direction, the measurement range, compression rate, y position can be changed and the cursor can be moved. rical direction, the measurement range for the input matically set.) rical direction can be changed and the cursor can be moved. rican be allocated. rical sampling rate and measurement range for the input matically set.) rically set.) rically set.

#### Option Specifications (sold separately)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 280 g (9.9 oz) Accessories: None



HIGH SPEED ANAL U8976	OG UNIT  (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 M $\Omega$ , input capacitance 22 pF) Max. rated voltage to ground: 1000 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/500/5 k/1 MHz
Measurement resolution	1/1600 of measurement range (using 12-bit A/D conversion)
Maximum sampling rate	200 MS/s (simultaneous sampling in 2 channels)
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 30 MHz -3 dB (with AC coupling: 7 Hz to 30 MHz -3 dB)
Input coupling	AC/DC/GND
Maximum input voltage	400 V DC (with direct input), 1000 V DC (with 9665)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz)



ANALOG UNIT 8966  up time and zero adjustment. Accuracy guaranteed for 1 year, Postadjustment accuracy guaranteed for 1 year, Postadjustment functions  No. of channels: 2, for voltage measurement  Isolated BNC connector (input impedance 1 MO, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channel without damage)  100, 200, 400 mV f.s. 1, 24, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz  Measurement resolution  1/2000 of measurement range (using 12-bit A/D conversion)  Maximum sampling rate  Measurement accuracy ±0.5% f.s. (with filter 5 Hz, zero position accuracy included)  Frequency characteristics  DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)  Maximum input voltage 400 V DC (the maximum voltage that can be applied across input pins without	Accessories: No	lle .
Isolated BNC connector (input impedance 1 MC, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)  100, 200, 400 mV f.s. 1, 24, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz  Measurement 1/2000 of measurement range (using 12-bit A/D conversion)  Maximum sampling rate 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 3 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 3 channels)  Measurement accuracy 20 MS/s (simultaneous sampling across 2 channels)	ANALOG UNIT 896	
Input terminals  Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)  100, 200, 400 mV f.s. 1, 24, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz  Measurement resolution  1/2000 of measurement range (using 12-bit A/D conversion)  Maximum sampling rate  Measurement accuracy ±0.5% f.s. (with filter 5 Hz, zero position accuracy included)  Frequency characteristics  DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)  Input coupling  AC/DC/GND  Maximum input voltage  400 V DC (the maximum voltage that can be applied across input pins without	Measurement functions	No. of channels: 2, for voltage measurement
1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 M/50 K/500 KHz	Input terminals	Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and
resolution    Maximum sampling rate   20 MS/s (simultaneous sampling across 2 channels)	Measurement range	1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms
Measurement accuracy		1/2000 of measurement range (using 12-bit A/D conversion)
Frequency characteristics DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)  Input coupling AC/DC/GND  Maximum input voltage 400 V DC (the maximum voltage that can be applied across input pins without	Maximum sampling rate	20 MS/s (simultaneous sampling across 2 channels)
characteristics DC to 5 MHz -3 08 (with AC coupling: / Hz to 5 MHz -3 08)  Input coupling AC/DC/GND  Maximum input voltage 400 V DC (the maximum voltage that can be applied across input pins without	Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)
Maximum input voltage 400 V DC (the maximum voltage that can be applied across input pins without		DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)
	Input coupling	AC/DC/GND
danage/	Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4CH ANALOG UNI	T U8975	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4,	for voltage measurement
Input terminals	Max. rated voltage maximum voltage t	ector (input impedance 1 $M\Omega$ , input capacitance 30 pF), to ground: 300 V AC, DC (with input isolated from the unit, the hat can be applied between input channel and chassis and innels without damage)
Measurement range		200 V f.s., 6 ranges sible measurement/display: 140 V rms 00/5 k/200 kHz
Measurement resolution	1/32,000 of measu	rement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneo	us sampling in 4 channels)
Measurement accuracy	±0.1% f.s. (with filter	er 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB	
Input coupling	DC / GND	
Maximum input voltage	200 V DC (the max damage)	imum voltage that can be applied across input pins without

NEW Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



Accessories: None		0.000
4CH ANALOG UNI	T U8978	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4,	for voltage measurement
Input terminals	Max. rated voltage (CAT II) when con	ector (input impedance 1 $M\Omega$ , input capacitance 30 pF), to ground: 30 V AC or 60V DC for direct input, 300 V AC, DC nbined with the 9665 (Between each input channel and the ween the input channels)
Measurement range	100, 200, 400 mV f 1, 2, 4, 10, 20, 40 V Low-pass filter: 5/5	f.s., 9 ranges
Measurement resolution	1/32,000 of measu	rement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneo	us sampling in 4 channels)
Measurement accuracy	±0.3% f.s. (with filte	er 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB	
Input coupling	DC / GND	
Maximum input voltage	40 V DC (with direct	et input), 400 V DC (with 9665)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



710000001100.110	
HIGH RESOLUTIO 8968	N UNIT  (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement
Input terminals	Isolated BNC connector (input impedance $1\mathrm{M}\Omega$ , input capacitance $30\mathrm{pF}$ ), Max. rated voltage to ground: $300\mathrm{V}\mathrm{AC}$ , DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 kHz
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)
Input coupling	AC/DC/GND
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



Accessories, Ivol	
DC/RMS UNIT 897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable
Input terminals	Isolated BNC connector (input impedance 1 M $\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/100 kHz
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)
RMS measurement	RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz) ±3% f.s. (1 kHz to 100 kHz) Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), FAST 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2
Frequency characteristics	DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)
Input coupling	AC/DC/GND
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



71000000110011100	
HIGH-VOLTAGE U U8974	NIT  (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable Max. rated voltage to ground: 1000 V AC,DC for measurement category III, 600 V AC, DC for measurement category IV
Input terminals	Banana input terminal (Input impedance: 4 MΩ, Input capacitance: 5 pF)
Measurement range	4, 10, 20, 40, 100, 200, 400, 1000 V f.s. (DC mode), 8 ranges 10, 20, 40, 100, 200, 400, 1000 V f.s. (RMS mode), 7 ranges Low-pass filter: 5/50/500/5 k/50 kHz
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	1 MS/s
Measurement accuracy	±0.25% f.s. (with filter 5 Hz, zero position accuracy included)
RMS measurement	RMS accuracy: ±1.5% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s
Frequency characteristics	DC to 100 kHz -3 dB
Input coupling	DC / GND
Maximum input voltage	1000 V DC, 700 V AC

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 260 g (9.2 oz)



Accessories: Non	e e
DIGITAL VOLTMET MR8990	FER UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and calibration, Accuracy guaranteed for 1 year, Postadjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for DC voltage measurement
Input terminals	Banana input connectors (Input resistance: $100\mathrm{M}\Omega$ or higher with $100\mathrm{m}V$ f.s. to $10\mathrm{V}$ f.s. range, otherwise $10\mathrm{M}\Omega$ ) Max. rated voltage to ground: $300\mathrm{V}$ AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)
Integration Time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)
Response time	2 ms +2× integration time or less (rise - f.s. → + f.s., fall + f.s. → - f.s.)
Basic measurement accuracy	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 245 g (8.6 oz) Accessories: CONVERSION CABLE L9769  $\times$  2 (cable length 60 cm (1.97 ft))



STRAIN UNIT U89	69 warm-up time and auto-balance; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for distortion measurement (electronic auto-balancing, balance adjustment range within ±10,000 με or less)
Input terminals	NDIS connector EPRC07-R9FNDIS (via CONVERSION CABLE L9769, NDIS connector PRC03-12A10-7M10.5) Max. rated voltage to ground: 30 V AC rms or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)
Suitable transducer	Strain gauge converter, Bridge impedance: 120 $\Omega$ to 1 k $\Omega$ , Bridge voltage: 2 V ±0.05 V, Gauge rate: 2.0
Measurement range	400, 1000, 2000, 4000, 10,000, 20,000 με f.s., 6 ranges Low-pass filter: 5/10/100/1 kHz
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	200 kS/s (simultaneous sampling across 2 channels)
Measurement accuracy After auto-balancing	±0.5% f.s. ±4 με (5 Hz filter ON)
Frequency characteristics	DC to 20 kHz +1/-3 dB

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



CHARGE UNIT U897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm- up time and zero adjustment; Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for acceleration measurement
Input terminals	Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance 1 MΩ, input capacitance 200 pF or less) Charge input: Miniature connector (#10-32UNF) Max. rated voltage to ground: 30 V AC or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)  *Voltage input terminal GND and charge input terminal GND for the same channel are shared.
Suitable transducer	Charge output type acceleration detector Pre-amp embedded acceleration detector (IEPE type)
Measurement range Charge input (Miniature connector) Pre-amp embedded input (BNC connector)	1 (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC /(m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV /(m/s²) Amplitude accuracy: ±2% f.s. Frequency characteristics: 1(1.5) to 50 kHz -3 dB (charge input) Low-pass filter: 500/5 kHz Pre-amp supply power: 3.5 mA ±20%. 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side)
Measurement range Voltage input (BNC connector)	10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND Maximum input voltage: 40 V DC
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	200 kS/s
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)
TEDS	IEEE 1451.1.4 class 1 support (Support for sensor information reading and automatic sensitivity setting)

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: CONVERSION CABLE 9318  $\times$  2 (To connect the current sensor to the 8971)



CURRENT UNIT 897	71 up time and zero adjustment; Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, Current measurement with optional current sensor
Input terminals	Sensor connector (input impedance 1 $M\Omega$ , exclusive connector for current sensor via conversion cable the 9318, common GND with recorder)
Compatible current sensors	CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)
Measurement range	Using 9272-10 (20 A), CT6841: 2 A to 100 A f.s., 6 ranges Using CT6862: 4 A to 200 A f.s., 6 ranges Using 9272-10 (200 A), CT6843, CT6863: 20 A to 1000 A f.s., 6 ranges Using CT6844, CT6845, 9709, CT6846*1, CT6865*1: 40 A to 2000 A f.s., 6 ranges *1: The conversion ratio needs to be set to 2 for scaling.
Measurement accuracy (with 5 Hz filter ON)	RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz)
Note: Add the accuracy and attributes of the current sensor being used.	RMS response time: 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2 Frequency characteristics: DC to 100 kHz ±3 dB (with AC coupling: 7 Hz to 100 kHz)
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)
Other functions	Input coupling: AC/DC/GND, Low-pass filter: 5/50/500/5 k/50 kHz

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 190 g (6.7 oz) Accessories: None



710000001100.1	VOTE
LOGIC UNIT 8973	
Measurement functions	No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)
	Mini DIN connector (for HIOKI logic probes only), Compatible logic probes: 9320-01, 9327, MR9321-01

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



3CH CURRENT UN U8977	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year.						
Measurement functions	No. of channels: 3, Current measurement with optional current sensor						
Input terminals	Dedicated connector terminal (ME15W) (input impedance 1 MΩ, common GND with recorder)						
Compatible current sensors	9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6846-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876 (Direct connection) CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045, CT7046 (Connection using optional CONVERSION CABLE CT9920)						
Measurement range	- Directly connected current sensor: Automatically identify rating of compatible current sensors  Using 9272-05 (20 A), CT6841-05: 2 A to 100 A f.s., 6 ranges  Using 9272-05 (20 A), CT6841-05: 2 A to 100 A f.s., 6 ranges  Using 9272-05 (200 A), CT6843-05, CT6863-05: 20 A to 1000 A f.s., 6 ranges  Using 9272-05 (200 A), CT6843-05, CT6904, CT6875: 40 A to 2000 A f.s., 6 ranges  Using CT6846-05, CT6865-05, CT6876: 80 A to 4000 A f.s., 6 ranges  - Current sensors connected using CT9920: Select conversion rate or model  Using CT7631, CT7731: 200 A, 1 range  Using CT7642, CT7742: 2000 A/4000 A, 2 ranges  Using CT7644, CT77045, CT7046: 2000 A to 10,000 A, 3 ranges						
Measurement accuracy (with 5 Hz filter ON) Note: Add the accuracy and attributes of the current sensor being used.	±0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB						
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)						
Maximum sampling rate	5 MS/s (simultaneous sampling in 3 channels)						
Other functions	Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz						

Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 204.5 mm (8.05 in) D, approx. 240 g (8.5 oz) Accessories: Ferrite clamp x 2



TEMP UNIT 8967	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)							
Measurement functions	No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)							
Input terminals	Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter $\phi$ 0.18 mm (0.01 in) or more), AWG 26 to 16 Input impedance: min. 5 M $\Omega$ (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)							
Temperature measurement range Note: Upper and lower limit values depend on the thermocouple	200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges  Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion)							
Thermocouple range (JIS C 1602-1995) (ASTM E-988-96)	K: -200°C to 1350°C (-328°F to 2462°F), J: -200°C to 1100°C (-328°F to 2012°F), E: -200°C to 800°C (-328°F to 1472°F), T: -200°C to 400°C (-328°F to 752°F), N: -200°C to 1300°C (-328°F to 2372°F), R: 0°C to 1700°C (32°F to 3092°F), S: 0°C to 1700°C (32°F to 3092°F), B: 400°C to 1800°C (752°F to 3272°F), W(WRe5-26): 0 to 2000°C (32°F to 3632°F) Reference junction compensation: internal/ external (switchable), line fault detection ON/OFF possible							
Data refresh rate	3 methods, Fast:1.2 ms (digital filter OFF), Normal:100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)							
Measurement accuracy	Thermocouple K, J, E, T, N: $\pm$ 0.1% f.s. $\pm$ 1°C ( $\pm$ 1.8°F), ( $\pm$ 0.1% f.s. $\pm$ 2°C ( $\pm$ 3.6°F) at -200°C to 0°C ( $\pm$ 3.6°F to 32°F)) Thermocouple R, S, B, W: $\pm$ 0.1% f.s. $\pm$ 3.5°C ( $\pm$ 6.3°F)(at 0°C (32°F) to less than 400°C (752°F); However, no accuracy guarantee at less than 400°C (752°F) for B), $\pm$ 0.1% f.s. $\pm$ 3°C ( $\pm$ 5.4°F) (at 400°C or more) Reference junction compensation (RJC] accuracy: $\pm$ 1.5°C ( $\pm$ 2.7°F) (added to measurement accuracy with internal reference junction compensation)							


Dimensions/mass: approx. 106 mm (4.17 in) W x 19.8 mm (0.78 in) H x 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



FREQ UNIT 8970	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)					
Measurement functions	No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width					
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF), $Max$ , rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)					
Frequency mode	Measurement range: Between DC to 100 kHz (minimum pulse width 2 µs), 20 Hz to 100 kHz f.s., 8 ranges Accuracy: ±0.1% f.s. (exclude 100 kHz range), ±0.7% f.s. (100 kHz range)					
Rotation mode	Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2 µs), 2 kr/min to 2 Mr/min f.s, 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)					
Power frequency mode	Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)					
Integration mode	Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.					
Duty ratio mode	Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 μs), 100% f.s. Accuracy: ±1% (10 to 10 kHz), ±4% (10 k to 100 kHz)					
Pulse width mode	Measurement range: Between 2 μs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.					
Measurement resolution	0.0025% f.s. (Integration mode), 0.01% f.s. (exclude integration, power frequency mode), 0.01 Hz (power frequency mode)					
Input voltage range and threshold level	±10 V to ±400 V, 6 ranges, selectable threshold level at each range					
Other functions	Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling, Frequency dividing, Integration over-range keep/return					

### System Chart of Options

All prices are exclusive of tax.



Note: The main unit cannot operate alone

You must install one or more optional input modules in the unit. The Z5021, U8332, and U8333 are factory built-in options and cannot be installed by the user

#### Factory-installed option A \*Must specify when ordering

\*Power can be supplied to up to 9 current sensors, including the current sensors connected to the CURRENT UNIT US977 and CURRENT UNIT 8971.

00000000

PROBE POWER UNIT Z5021 Specified upon order, ±12 V DC, supply for up to 8 probes

#### Factory-installed option B

\*Must specify when ordering



SSD UNIT U8332 Specified upon order; built-in type, 256 GB

#### Factory-installed option C



HD UNIT U8333 Specified upon order; built-in type, 320 GB

#### Storage media

\*Use only the storage media sold by HIOKI. Compatibility and performance are not guaranteed for storage media made by other manufacturers. You may be unable to read from or save data to such media.



SD MEMORY CARD Z4001

SD MEMORY CARD Z4003

8 GB

USB DRIVE Z4006

16 GB Using highly durable and reliable SLC flash

#### Case



CARRYING CASE C1010

For the MR6000, hard trunk type, for storing



CONNECTION CABLE L9795-01

Max. rated voltage to ground: 33 V AC rms or 70 V DC, SMB terminal to alligator clip, 1.5 m (4.92 ft)



CONNECTION CABLE L9795-02

Max. rated voltage to ground: 33 V AC rms or 70 V DC, SMB terminal to BNC terminal, 1.5 m (4.92 ft)

## Input modules



HIGH SPEED ANALOG UNIT U8976 2 ch, voltage input, 200 MS/s, (DC to 30 MHz)

ANALOG UNIT 8966

2 ch, voltage input, 20 MS/s, (DC to 5 MHz)



4CH ANALOG UNIT U8975 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), Input voltage limit: 200 V DC



4CH ANALOG UNIT U8978 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.



HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)



DC/RMS UNIT 8972 2 ch, voltage/1 MS/s, (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz)



HIGH-VOLTAGE UNIT U8974

2 ch, voltage input, max. 1000 V DC and 700 V AC



2 ch, high-precision DC voltage, 0.1  $\mu V$  resolution, maximum sampling rate 500 times/s

3CH CURRENT UNIT U8977



3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units



**CURRENT UNIT 8971** 

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units



TEMP UNIT 8967 2 ch, thermocouple temperature input

STRAIN UNIT U8969



2 ch, strain gauge type converter amp **CONVERSION CABLE L9769** 

(for STRAIN UNIT U8969 only, included)



2 ch, for measurement of frequency, RPM, pulse, etc.

FREQ UNIT 8970

CHARGE UNIT U8979



2 ch, for acceleration measurement, supports charge output, pre-amp output (IEPE type), and voltage output



LOGIC UNIT 8973

4 terminals, 16 ch, installable in all 8 slots

#### Logic signal measurement



#### LOGIC PROBE 9327 LOGIC PROBE 9320-01

4-channel type, for voltage/contact signal ON/OFF

Not isolated Response pulse width: 500 ns or more (9320-01), 100 ns or more (9327) Digital input threshold: 1.4 V / 2.5 V / 4.0 V Maximum input voltage: 0 to +50 V DC



Logic Probe MR9321-01

Logic Probe MH93/21-01
4 channels, ON/OFF detection of AC/DC voltage Isolated
Response time: rising, 1 ms or less; falling, 3 ms or less
Output (H) detection: 170 to 250 V AC, ±(70 to 250) V DC (HIGH range)
60 to 150 V AC, ±(20 to 150) V DC (LOW range)
Output (L) detection: 0 to 30 V AC, ±(0 to 43) V DC (HIGH range)
0 to 10 V AC, ±(0 to 15) V DC (LOW range)
Maximum input voltage: 250 Vrms (HIGH range),
150 Vrms (LOW range)

#### Non-contact CAN measurement



Non-Contact CAN Sensor SP7001-90

CAN FD/CAN support, bundle including SP7001/SP7100/SP9200, use by connecting to Vector interface or similar product,

Non-Contact CAN Sensor SP7002-90

CAN support, bundle including SP7002/SP7100/SP9200, use by connecting to Vector interface or similar

#### **PC Software**



MR6000 Viewer Software that provides operability similar to the MR6000, allowing you to load measurement data, display waveforms, and perform calculations ...Free download



Waveform Viewer Wv VIAVETORM VIEWER WV
Software for checking
waveforms with binary data
on a PO, saving data in CSV
format, and transferring to
spreadsheet programs

..Standard accessory



PC display for massive amounts of waveform data and more



For details, see product information on Hioki's website.

#### \*Voltage is limited to the specifications of the input modules in use. INPUT CORD (A) CONNECTION CORD L9790 Flexible $\phi$ 4.1 mm (0.16 in) thin dia. cable allow for up to 600 V input, 1.8 m (5.91 ft) length

\*The end clip is sold separately

ALLIGATOR CLIP L9790-01 Red/black set attaches to the ends of the cables L9790

GRABBER CLIP 9790-02 \*When this clip is attached to the end of the L9790, input is limited to CAT II 300 V. Red/black set.

CONTACT PIN 9790-03

Red/black set attaches to the ends of the

#### \*Voltage is limited to the specifications of the input modules in use. INPUT CORD (B)

CONNECTION CORD L9198 φ 5.0 mm (0.20 in) dia., cable allowing for up to 300 V input, 1.7 m (5.58 ft) length, small alligator clip

CONNECTION CORD L9197  $\varphi$  5.0 mm (0.20 in) dia., cable allowing for up to 600 V input, 1.8 m (5.91 ft) length, detachable large alligator clips are bundled

**GRABBER CLIP 9243** Attaches to the tip of the L9197, red/black set, full length: 196 mm (7.72 in)

\*The maximum input voltage is derated based on the input frequency. For details, see the 10:1 PROBE 9665 user manual. INPUT CORD (C)



10:1 PROBE 9665

Max. rated voltage to ground is same as for input module, 1.5 m (4.92 ft) length



100:1 PROBE 9666

Max. rated voltage to ground is same as for input module, 1.5 m (4.92 ft) length

## INPUT CORD (D) "Voltage to ground is within this product's specifications. "Separate power source is also required."



DIFFERENTIAL PROBE P9000-01 (Wave Only) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

DIFFERENTIAL PROBE P9000-02 (Switch between Wave/RMS) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

AC ADAPTER 71008 100 to 240 V AC

INPUT CORD (E) "Voltage to ground is within this product's specifications.



DIFFERENTIAL PROBE 9322

1 kV AC, 2 kV DC, Frequency band: 10 MHz AC ADAPTER 9418-15

POWER CORD 9248

Supply power from PROBE POWER UNIT Z5021 to total of eight 9322 probes, 70 cm (2.29 ft)

## INPUT CORD (F) \*Voltage input via banana terminals lin voltage specifications of the respective



**EXTENSION CABLE L4931** 

Extend the length of banana plug cables, Cable length: 1.5 m (4.92 ft)

ALLIGATOR CLIP L4935

Attach to the tip of banana plug cables, CAT IV 600 V, CAT III 1000 V

BUS BAR CLIP L4936

Attach to the tip of banana plug cables, CAT III

MAGNETIC ADAPTER L4937

Attach to the tip of banana plug cables, CAT III

GRABBER CLIP 9243

Attach to the tip of banana plug cables, red/black set, full length: 196 mm (7.72 in), CAT III 1000 V

## INPUT CORD (G) \*For the MR8990 \*Voltage is limited to the specifications of the input modules in use



TEST LEAD L2200

Cable length: 70 cm (2.30 ft), tips interchangeable with a pin test lead or alligator clip, maximum input voltage: CAT IV 600 V, CAT III 1000 V

#### High-precision current measurement \*ME15W (12-pin) terminal type \*Directly connect to U8977

High-precision pull-through current sensors, observe wa from DC to distorted AC

AC/DC CURRENT SENSOR CT6862-05, 1 MHz, 50 A AC/DC CURRENT SENSOR CT6863-05, 500 kHz, 200 A Observe waveforms from DC to distorted AC AC/DC CURRENT PROBE CT6841-05, 1 MHz, 20 A AC/DC CURRENT PROBE CT6843-05, 500 kHz, 200 A

Observe AC waveforms (cannot observe DC) CLAMP ON SENSOR 9272-05, 100 kHz, 200 A

High-precision pull-through current sensors, observe waveforms from DC to distorted AC

AC/DC CURRENT SENSOR CT6904, 4 MHz, 500 A High-precision pull-through current sensors, obser from DC to distorted AC

AC/DC CURRENT SENSOR CT6875, 2 MHz, 500 A AC/DC CURRENT SENSOR CT6876, 1.5 MHz, 1000 A High-precision pull-through current sensors, observe from DC to distorted AC

AC/DC CURRENT SENSOR CT6877, 1 MHz, 2000 A Observe waveforms from DC to distorted AC AC/DC CURRENT PROBE CT6844-05, 200 kHz, 500 A

AC/DC CURRENT PROBE CT6845-05, 100 kHz, 500 A

AC/DC CURRENT PROBE CT6846-05, 20 kHz, 1000 A

## cautions when connecting the CURRENT UNIT 8971 with a high-precision current sensor

- High-precision current sensor (ME15W) + CT9901 + 9318 → CURRENT UNIT 8971 High-precision current sensor (ME15W) + CT955x + BNC cable → except CURRENT UNIT 8971
- High-precision current sensor (PL23) + 9318 → CURRENT UNIT 8971 High-precision current sensor (PL23) + CT9900 + CT955x + BNC cable CURRENT UNIT 8971
- CURRENT UNIT 89/1 The 9318 is bundled with the CURRENT UNIT 8971.

Combine the high-precision current sensor and the power supply to perform current measurements with a voltage input unit ors with ME15W (12-pin) terminals (-05 type) can be conne

The separately available CONVERSION CABLE CT9900 is re to use a sensor with a PL23 (10-pin) terminal.

#### POWER SUPPLY for Sensors SENSOR UNIT CT9555 1 ch, with waveform output

CONNECTION CORD L9217 Both cord ends are isolated BNC, 1.6 m (5.25 ft)

#### PL23 (10-pin) - ME15W (12-pin) conversion



CONVERSION CABLE CT9900 Convert PL23 (10-pin) terminal to ME15W (12-pin) terminal

vavailable CONVERSION CABLE CT9901 is required in high-precision current sensor equipped with a ME15W at (-05 type) with the CURRENT UNIT 8971.

## ME15W (12-pin) - PL23 (10-pin) conversion


CONVERSION CABLE CT9901 Convert ME15W (12-pin) terminal to PL23 (10-pin) terminal

#### Other current sensor type

The MEMORY HICORDER can be used with various types of current sensors and probes

#### ---- U8977 only

## High sensitivity, wideband current measurement



CLAMP ON PROBE 3273-50 Frequency characteristics: DC to 50 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3276 Frequency characteristics: DC to 100 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3274

Frequency characteristics: DC to 10 MHz wideband response, up to 150 A rms CLAMP ON PROBE 3275 Frequency characteristics: DC to 2 MHz wideband response, up to 500 A rms

**CURRENT PROBE CT6710** Frequency characteristics: DC to 50 MHz wideband response, 0.5 A-class up to 30 A rms

CURRENT PROBE CT6711
Frequency characteristics: DC to 120 MHz wideband response, 0.5 A-class up to 30 A rms

- (1) Bus powered USB cable
- (2) USB(A)- Micro B cable
- (3) 3-prong cable

#### Custom cable For P9000. Inquire with your local Hioki distributor.

#### Non-contact voltage measuring



NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width NON-CONTACT AC VOLTAGE PROBE SP3000

AC VOLTAGE PROBE SP9001 Sold individually

#### Other options for input



#### Temperature sensor



#### INPUT CABLE (H)



CONNECTION CABLE 9166 BNC - clips, cable length: 1.5 m (4.92 ft)

#### General-purpose current measurement \*PL14 terminal type

AC/DC AUTO ZERO CURRENT SENSOR CT7731 DC, 1 Hz to 5 kHz, 100 A

AC/DC AUTO ZERO CURRENT SENSOR CT7736 DC, 1 Hz to 5 kHz, 600 A

AC/DC AUTO ZERO CURRENT SENSOR CT7742 DC, 1 Hz to 5 kHz, 2000 A

1 AC/DC CURRENT SENSOR CT7631 DC. 1 Hz to 10 kHz, 100 A

AC/DC CURRENT SENSOR CT7636 DC, 1 Hz to 10 kHz, 600 A

AC/DC CURRENT SENSOR CT7642 DC, 1 Hz to 10 kHz, 2000 A

AC FLEXIBLE CURRENT SENSOR CT7044 φ100 mm (3.94 in), 6000 A

AC FLEXIBLE CURRENT SENSOR CT7045 ф180 mm (7.09 in), 6000 A AC FLEXIBLE CURRENT SENSOR CT7046

ф254 mm (10.00 in), 6000 A arately available CONVERSION CABLE CT9920 is in order to connect a PL14 terminal general-purpose sensor to the CURRENT UNIT U8977.

#### PL14 - ME15W (12-pin) conversion



CONVERSION CABLE CT9920 Convert PL14 terminal to ME15W (12-pin)

#### Leak Current \*For commercial power lines, 50/60 Hz



CLAMP ON LEAK HITESTER 3283 10 mA range / 10  $\mu A$  resolution to 200 A range, with monitor / analog output 1 V f.s.

OUTPUT CORD L9095 Connect to BNC terminal, 1.5 m (4.92 ft) length AC ADAPTER 9445-02

## 100 to 240 V AC Precautions for connecting current

\*Depending on the combination of current sensors and current probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables please inquire with your local distributor.

sensors and current probes

\*A total of 9 current sensors and current probes can be connected simultaneously to the Memory HiCorder. However, when using the CT6710 or CT6711, a total of 4 probes can be connected. (Total with the CURRENT UNIT U8977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

\*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory HiCorder.

\*If combining a current sensor or current probe with a sensor power source and using the voltage input analog unit for current measurement, there is no limitation on the number of connections

\*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.

## R&D testing and analysis

## Meeting the demanding requirements of a broad range of industries



Increased efficiency of inverters and improved performance of energy-saving technologies have been achieved in the power electronics, renewable energy, and automotive industries.

We have drastically improved the technology used in our Memory HiCorders, developing the MR6000 Memory HiCorder to meet the advanced demands of all industries.

#### Unit selection guide (15 types)

Unit interchangeability

The following units are compatible with the MR6000. Some units in the list are also compatible with the MEMORY HiCORDER MR8827, MR8847A, MR8740, MR8741, and MR8740-50. Please check the brochure of each product.

Measured signal	Model	Description	No. of channels	Fastest sampling	Bandwidth	A/D resolution	DC accuracy	Max. input voltage	Sensitivity (#1)	Max. sensitivity range	Isolation	Supplement
Voltage (high speed)	U8976	High-Speed Analog Unit	2 ch	200 MS/s	DC to 30 MHz	12 bits	±0.5% f.s.	400 V DC 1000 V DC (#2)	0.0625 mV	100 mV f.s.	Yes	n/a
Voltage	8966	Analog Unit	2 ch	20 MS/s	DC to 5 MHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	n/a
Voltage (4ch)	U8975	4ch Analog Unit	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.1% f.s.	200 V DC	0.125 mV	4 V f.s.	Yes	n/a
Voltage (4ch, high resolution)	U8978	4ch Analog Unit	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	40 V DC	3.125 uV	100 mV f.s.	Yes	n/a
Voltage (high resolution)	8968	High Resolution Unit	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.3% f.s.	400 V DC	3.125 uV	100 mV f.s.	Yes	with AAF
Voltage (DC, RMS)	8972	DC/RMS Unit	2 ch	1 MS/s	DC to 400 kHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	with RMS
Voltage (high voltage)	U8974	High Voltage Unit	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.25% f.s.	1000 V DC 700 V AC	0.125 mV	4 V f.s.	Yes	n/a
Voltage (high resolution)	MR8990	Digital Voltmeter Unit	2 ch	2 ms	n/a	24 bits	±0.01% rdg. ±0.0025% f.s.	500 V DC	0.1 uV	100 mV f.s.	Yes	n/a
Current	U8977	3ch Current Unit	3ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	Current sensor only		on current nsor	n/a	Max. 3 Units
Current	8971	Current Unit	2 ch	1 MS/s	DC to 100 kHz	12 bits	±0.65% f.s.	Current sensor only		on current nsor	n/a	with RMS Max. 4 Units
Temperature	8967	Temperature Unit	2 ch	1.2 ms	DC	16 bits	Detailed reference	Thermocouples only	0.01°C	200°C (392°F)f.s.	Yes	n/a
Strain	U8969	Strain Unit	2 ch	200 kS/s	DC to 20 kHz	16 bits	±0.5% f.s. ±4 με	Strain only	0.016 με	400 μεf.s.	Yes	n/a
Frequency	8970	Frequency Unit	2 ch	200 kS/s	DC to 100 kHz (#3)	16 bits	n/a	400 V DC	0.002 Hz	Depends on mode	Yes	n/a
Acceleration	U8979	Charge Unit	2 ch	200 kS/s	DC to 50 kHz (DC) 1 Hz to 50 kHz (AC)	16 bits	±0.5% f.s. (Voltage) ±2.0% f.s. (Acceleration)	40 V DC		nds on tion sensor	Yes	Supports TEDS
Logic	8973	Logic Unit	4 probes (16 ch)	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	Requires 9320-01, 9327 or MR9321-01

(#1) Minimum resolution shows the highest sensitivity resolution. (#2) When using the 9665 (#3) Minimum pulse width  $2 \mu s$ 

Note: Company names and product names appearing in this catalog are trademarks or registered trademarks of various companies.



**HEADQUARTERS** 

81 Koizumi, Ueda, Nagano 386-1192 Japan https://www.hioki.com/



Scan for all regional contact information

DISTRIBUTED BY